

FACE

Automatic Doors

ENGLISH

INSTALLATION AND MAINTENANCE MANUAL FOR SWING DOOR



SW80S SPRING
SW80S1 LIGHT SPRING

1. INTRODUCTION

Before you begin to install or start an automatic pedestrian doors, an inspection must be carried out on site by qualified personnel, for making measurements of the compartment wall, door and drive.

This inspection is to assess the risk and to select and implement the most appropriate solutions according to the type of pedestrian traffic (intense, narrow, one-way, bi-directional, etc.), The type of users (elderly, disabled, children, etc.), in the presence of potential hazards or local circumstances.

To assist installers in applying the requirements of European Standard EN 16005 concerning the safe use of automatic pedestrian doors, we recommend consulting the guides E.D.S.F. (European Door and Shutter Federation) available on www.edsf.com.

1.1 GENERAL SAFETY INSTRUCTION

This installation manual is intended for professionally competent personnel only. Before installing the product, carefully read the instructions. These instructions must be kept.

WARNING: Important safety instructions. Follow all instructions since incorrect installation can lead to severe injury.

The packaging materials (plastic, polystyrene, etc.) should not be discarded in the environment or left within reach of children, as these are a potential source of hazard.

Before installing the product, make sure it is in perfect condition. Do not install the product in an explosive environment and atmosphere: gas or inflammable fumes are a serious hazard risk.

Before installing the automations, make all structural changes relating to safety clearances and protection or segregation of all areas where there is risk of being crushed, cut or dragged, and danger areas in general.

Make sure the existing structure is up to standard in terms of strength and stability. FACE is not responsible for failure to use Good Working Methods in building the frames to be motorised or for any deformation occurring during use.

The safety devices (safety sensor, photocells, etc.) must be installed taking into account: applicable laws and directives, Good Working Methods, installation premises, system operating logic and the forces developed by the motorised door.

Apply hazard area notices required by applicable regulations.

The emission sound pressure level of the door is $LpA \leq 70dB(A)$.

Each installation must clearly show the identification details of the automatic pedestrian door.

1.2 EC MARKING AND EUROPEAN DIRECTIVES



Automations for swing pedestrian door, are designed and manufactured in compliance with the safety requirements of the European standard EN 16005 and are CE-marked in accordance with the Electromagnetic Compatibility Directive (2014/30/UE).

The automation also include a Declaration of Incorporation according to the Machinery Directive (2006/42/EC).

Pursuant to Machinery Directive (2006/42/CE) the installer who motorises a door or gate has the same obligations as the manufacturer of machinery and as such must:

- prepare the technical file which must contain the documents indicated in Annex V of the Machinery Directive; (The technical file must be kept and placed at the disposal of competent national authorities for at least ten years from the date of manufacture of the pedestrian door);
- draft the EC declaration of conformity in accordance with Annex II-A of the Machinery Directive and deliver it to the customer;
- affix the CE marking on the power operated door in accordance with point 1.7.3 of Annex I of the Machinery

All data and information contained in this manual have been drawn up and checked with the greatest care. However FACE cannot take any responsibility for eventual errors, omissions or inaccuracies due to technical or illustrative purposes.

FACE reserves the right to make changes and improvements to their products. For this reason, the illustrations and the information appearing in this document are not definitive.

This edition of the manual cancels and replaces all previous versions. In case of modification will be issued a new edition.



DECLARATION OF INCORPORATION

Machines Directive 2006/42/EC, Annex II-B

FACE S.r.l.

Viale delle Industrie, 74 - 31030 Dosson di Casier (TV) - ITALY

Declares that:

The Product automations for power operated pedestrian swing door type: **SW80S, SW80S1**

Has been built for installation on pedestrian door and constitutes a machine in accordance with Directive 2006/42/EC. The manufacturer of the power operated pedestrian door must declare its conformity in accordance with Directive 2006/42/EC (Annex II-A) prior to starting-up the machine.

It complies with the applicable essential safety requirements specified in Annex I, chapter 1 of Directive 2006/42/EC.

It complies with the Electromagnetic Compatibility Directive 2014/30/UE.

It complies with following harmonized standards:

EN 16005 Power operated pedestrian doorsets - Safety in use - Requirements and test methods (chapters: 4.2, 4.3.1, 4.3.2, 4.3.3, 4.4.1, 4.4.4, 4.4.5, 4.6.1, 4.6.3, 4.6.4, 4.6.7, 4.6.8, 4.7.2.4, 5.1, 5.2, 5.3, 5.4, 5.5.3, 5.6, 5.8.1, 5.8.2, 5.8.3, 5.10)

EN 60335-2-103 Household and similar electrical appliances - Safety - Part 2: Particular requirements for drives for gates, doors and windows

The technical documentation complies with Annex VII-B to Directive 2006/42/EC.

The technical documentation is managed by: Ferdinando Menuzzo with registered offices in Viale delle Industrie, 74 - 31030 Dosson di Casier (TV) - ITALY

A copy of the technical documentation shall be supplied to the competent national authorities following duly motivated request.

Place and date:

Dosson di Casier, 2019-06-15

Paolo Bacchin
Managing Director

A handwritten signature in blue ink, appearing to read "Paolo Bacchin", is written over the printed name and title.

FACE S.r.l.

Viale delle Industrie, 74

31030 – Dosson di Casier (TV) Italy

Phone +39 0422 492730 Fax +39 0422 380414

www.facespa.it






Iscritta al Reg. Imp. di Treviso al n. 04552520266

C.F.-P.I. 04552520266

Capitale Sociale € 100.000,00 i.v.

R.E.A. di Treviso n. 359250

2. TECHNICAL DATA

| Technical data | SW80S | SW80S1 |
|--|---|---|
| Model | SPRING | LIGHT SPRING |
| Use | Opening by motor, closing by spring and motor | Opening by motor, closing by spring and motor, with easy manual handling |
| Reference standard | EN 16005 EN 1154 (closing force: EN4, EN5, EN6) | EN 16005 EN 1154 (closing force: EN4) |
| Type approval |  | - |
| Product dimensions (Height x Depth x Length) | 88 x 130 x 540 mm | 88 x 130 x 540 mm |
| Maximum load: | 300 kg x 0,8 m  | 300 kg x 0,8 m  |
| Opening and closing time | 2 – 6 s | 2 – 6 s |
| Duty class | Continuous operation | Continuous operation |
| Intermittent operation | S3 = 100% | S3 = 100% |
| Power supply | 100 – 240 Vac 50/60 Hz | 100 – 240 Vac 50/60 Hz |
| Rated power | 70 W | 70 W |
| Stand-by | 3 W | 3 W |
| Rated load | 40 Nm | 40 Nm |
| Protection Rating | IP 20 | IP 20 |
| Operating temperature |  |  |
| Parameter adjustment | Buttons and Display | Buttons and Display |
| Connections to control and safety devices | Dedicated connecting terminals | Dedicated connecting terminals |
| Number of programmable terminals | 4 (G1, G2, G3, G4) | 4 (G1, G2, G3, G4) |
| Power output for accessories | 12 Vdc (1A max) | 12 Vdc (1A max) |
| Power output for electric locks and electronic locks | 12 Vdc (1A max) / 24 Vdc (0,5 A max) | 12 Vdc (1A max) / 24 Vdc (0,5 A max) |
| Firmware update | USB standard | USB standard |
| Function selector device | FSD1, FSD4 | FSD1, FSD4 |
| Battery power device | SW80BD (for automations cut to size only) | SW80BD (for automations cut to size only) |

N.B. The technical data above refer to average conditions of use and cannot be certain in each case. Each automatic entrance variables such as: friction, balancing and environmental conditions that may substantially change both the duration and the quality of the operation of the automatic or some of its components, including the automation. The installer must to adopt adequate safety coefficients for each particular installation.

3. STANDARD INSTALLATION



| Rif. | Code | Description |
|------|------------|---|
| 1 | SW80S | SW80S automation (Spring) for swing doors |
| 2 | SW80SA | Sliding arm |
| 3 | SD3 | Safety sensor |
| 4 | OS1 | Opening sensor |
| 5 | FSD1, FSD4 | Electronic function selector |

Note: Components and codes are those most commonly used in systems for automatic swing doors. The full range of equipment and accessories is also available in the sales list.

The given operating and performance features can only be guaranteed with use of FACE accessories and safety devices.

4. ASSEMBLY PROCEDURE OF THE AUTOMATION


Check the stability, the weight of the leaf and that the movement is smooth and without friction (if necessary to reinforce the frame). Any closing door device must be removed or completely deactivated.


4.1 INSTALLATION OF SW80S AUTOMATION WITH SW80SA SLIDING ARM

Use the sliding arm to pull with doors which open inside (view from the automation).

Remove the cover and fix the automation in a stable and leveled way to the wall using the measurements shown in the figure; refer to the axis of the door hinges (if $X = 0$ mm, the maximum door opening is 90°).

Note: if necessary, you can change the measure H, between the automation and the door, by replacing the spacer, using the codes listed in the table.





FIXING THE SLIDING ARM AND PRE-CHARGING OF THE CLOSING SPRING

Fix the sliding arm on the door as shown in the figure.

Bring the door to the closed position, insert the sliding arm in the guide and fix to the automation.

Check that the screws (B) and (C) are completely unscrewed.

Unscrew the screw (A) by about $\frac{1}{2}$ turn using a 5 mm hexagon key.

Tighten the screw (B) until the motor pulley turns, and then tighten the screw (B) for about 1 turn.

Tighten the screw (A).

Tighten the screws (B) and (C).

ADJUSTMENT OF THE CLOSING SPRING

The automation is supplied with the closing spring regulated with minimum force.

To increase the closing force of the spring, tighten the screw (D) using a 6 mm hexagon key.

If necessary, to increase the braking of the closing spring, move the jumper on the BRAKE connector (F) of the electronic control to the position M (medium braking) or H (high braking).

ADJUSTMENT OF THE SMALL SPRING

The automation is supplied with the small spring regulated with minimum force.

To increase the closing force in the last 4 degrees, tighten the screw (E) using a 13 mm key.

To reduce the closing force in the last 4 degrees, unscrew the screw (E).

Move the door manually, and verify the correct opening and closing force.

WARNING: Adjust the opening mechanical stop inside the sliding guide.

CLOSING OF THE AUTOMATION COVER


Attach the cover profile to the base profile. To prevent the cover from being opened without the use of a tool, you can secure the cover to the heads at the holes, using the screws 2,9x9,5.


4.2 INSTALLATION OF SW80S AUTOMATION WITH SW80SA1 SLIDING ARM

Use the sliding arm to push with doors which open outside (view from the automation).

Remove the cover and fix the automation in a stable and leveled way to the wall using the measurements shown in the figure; refer to the axis of the door hinges.

Note: if necessary, you can change the measure H, between the automation and the door, by replacing the spacer, using the codes listed in the table.





FIXING THE SLIDING ARM AND PRE-CHARGING OF THE CLOSING SPRING

Fix the sliding arm on the door as shown in the figure. If the leaf width is reduced, shorten the sliding guide.

Bring the door to the closed position, insert the sliding arm in the guide and fix to the automation.

Check that the screws (B) and (C) are completely unscrewed.

Unscrew the screw (A) by about ½ turn using a 5 mm hexagon key.

Tighten the screw (B) until the motor pulley turns, and then tighten the screw (B) for about 1 turn.

Tighten the screw (A).

Tighten the screws (B) and (C).

ADJUSTMENT OF THE CLOSING SPRING

The automation is supplied with the closing spring regulated with minimum force.

To increase the closing force of the spring, tighten the screw (D) using a 6 mm hexagon key.

If necessary, to increase the braking of the closing spring, move the jumper on the BRAKE connector (F) of the electronic control to the position M (medium braking) or H (high braking).

ADJUSTMENT OF THE SMALL SPRING

The automation is supplied with the small spring regulated with minimum force.

To increase the closing force in the last 4 degrees, tighten the screw (E) using a 13 mm key.

To reduce the closing force in the last 4 degrees, unscrew the screw (E).

Move the door manually, and verify the correct opening and closing force.

WARNING: Adjust the opening mechanical stop inside the sliding guide.

CLOSING OF THE AUTOMATION COVER


Attach the cover profile to the base profile. To prevent the cover from being opened without the use of a tool, you can secure the cover to the heads at the holes, using the screws 2,9x9,5.


4.3 INSTALLATION OF SW80S AUTOMATION WITH SW80AA ARTICULATED ARM

Use the articulated arm to push with doors which open outside (view from the automation).

Remove the cover and fix the automation in a stable and leveled way to the wall using the measurements shown in the figure; refer to the axis of the door hinges.

Note: if necessary, you can change the measure H, between the automation and the door, by replacing the spacer, using the codes listed in the table.





FIXING THE ARTICULATED ARM AND PRE-CHARGING OF THE CLOSING SPRING

Fix the bracket of the articulated arm on the door, using the measurements shown in the figure.

Bring the door to the closed position, fix the articulated arm to the automation, and fix the other end of the articulated arm to the door.

Adjust the length of the semi-arm (X) so that the angle between the semi-arm (X) and the door is about 90°.

Check that the screws (B) and (C) are completely unscrewed.

Unscrew the screw (A) by about ½ turn using a 5 mm hexagon key.

Tighten the screw (B) until the motor pulley turns, and then tighten the screw (B) for about 1 turn.

Tighten the screw (A).

Tighten the screws (B) and (C).

ADJUSTMENT OF THE CLOSING SPRING

The automation is supplied with the closing spring regulated with minimum force.

To increase the closing force of the spring, tighten the screw (D) using a 6 mm hexagon key.

If necessary, to increase the braking of the closing spring, move the jumper on the BRAKE connector (F) of the electronic control to the position M (medium braking) or H (high braking).

ADJUSTMENT OF THE SMALL SPRING

The automation is supplied with the small spring regulated with minimum force.

To increase the closing force in the last 4 degrees, tighten the screw (E) using a 13 mm key.

To reduce the closing force in the last 4 degrees, unscrew the screw (E).

Move the door manually, and verify the correct opening and closing force.


WARNING: Install the opening mechanical stop.

Note: the mechanical stop on the floor must be fixed in a visible position and must not create tripping hazard.

CLOSING OF THE AUTOMATION COVER

Attach the cover profile to the base profile. To prevent the cover from being opened without the use of a tool, you can secure the cover to the heads at the holes, using the screws 2,9x9,5.

5. ELECTRICAL CONNECTIONS



| Rif. | Code | Terminals | Description |
|------|--------|------------|---|
| 1 | 2329 | MAINS IN | Cable for connection to the power supply. |
| 2 | 5EA12 | PWR | Switching power supply 42V |
| 3 | 5CB11 | | Electronic control |
| 4 | 2B9015 | MOT ENC | Brushless motor Angular sensor |
| 5 | SW80BD | BAT | Battery power device |
| 6 | | FUSE | Battery fuse 5x20 - F10A |

5.1 GENERAL SAFETY ELECTRICAL PRECAUTIONS

Installation, electrical connections and adjustments must be completed in conformity with Good Working Methods and with regulations in force.

Before connecting the power supply, make sure that the data on the label correspond to those of the mains supply.

A multipolar disconnection switch with a contact opening gap of at least 3 mm must be incorporated in the fixed wiring in accordance with the wiring rules. This switch must be protected from unauthorized activations.

Check that the mains supply is equipped with a suitable residual current circuit breaker and a 6 A overcurrent protection.

Connect the automation to an effective earthing system carried out as indicated by current safety regulations.

During installation, maintenance and repair operations, cut off the power supply before opening the cover to access the electrical parts. To handle electronic parts, wear earthed antistatic conductive bracelets.

FACE declines all responsibility in the event of components which are not compatible with the safe and correct operation of the product.

For repairs or replacements of products only original spare parts must be used.

5.2 POWER SUPPLY ELECTRICAL CONNECTION

The connection to the mains supply can be done in one of the two following ways.


1) ELECTRICAL CONNECTION THROUGH THE AUTOMATION BASE

Use the electric cable and the supplied terminals for the connection to the mains supply through a channel in the wall, previously made.

Note: Shorten the electric cable to the desired size.

Make sure there are no sharp edges that might damage the electric cable.


For the connection to the mains supply use an independent channel, separated from the connections to control and safety devices.




2) ELECTRICAL CONNECTION THROUGH THE AUTOMATION END CAP

If the path of the electric cable is outer the wall, drill the end cap on the suitable area, fix the electric cable using a supplied PG9 cable gland.

Connect the electric cable to the junction box (using the supplied terminals), or connect the electric cable to the wall socket using an electrical plug (not supplied by us).



5.3 ELECTRONIC CONTROL TERMINALS



Note: The terminals with the same number are equivalent.

The electronic control comes with the jumpers on the terminals with an asterisk [*]. When connecting safety devices remove the jumpers of the corresponding terminals.

| Terminals | Description |
|-----------------|---|
| 0 – 1 | Output 12 Vdc for external powering accessories. The maximum absorption of 1 A corresponds to the sum of all the terminals 1 (+12V). |
| 1 – 3A | Contact N.O. opening A side (interior side). |
| 1 – 3B | Contact N.O. opening B side (outer side). |
| 1 – 8A | Closing safety contact N.C. The opening of the contact causes the reversal of the movement. Note: connect safety devices with test (see terminal 41), and remove the jumper 41 - 8A. |
| 1 – 6A | Opening safety contact N.C. The opening of the contact stops the movement during the opening phase; the door closes after 3s. If the automation is closed, the opening of the contact prevents the opening. Note: connect safety devices with test (see terminal 41), and remove the jumper 41 - 6A. |
| 41 | Test output (+12 V). Connect the safety devices with test (in accordance with EN 16005), as indicated in the following chapters. Note: in case of devices without test, connect the N.C. contact to terminals 41 - 8A or 41 - 6A. |
| 1 – G1/G2/G3/G4 | Input terminal provided for general use. |
| 0 – G1/G2 | Output terminal (12 Vdc, 20 mA max) provided for general use. Using the ADV > STG1/STG2/STG3/STG4 menu you can choose a specific function to the G1/G2/G3/G4 terminal. |
| 0 – 1 – H – L | Bus connection to the function selector. |
| 0 – S – V | Future use |
| +LK / -LK | Output 12Vdc (1 A max) / 24Vdc (0,5 A max) for electric lock. |
| MAX | Connection for SW80SD optional limit switch to select the maximum braking in the absence of power supply. |
| BRAKE | Braking regulation in the absence of power supply: L = low, M = medium, H = high. |
| USB | USB standard. Allows saving the door settings and loading the firmware updates. |
| COM | Connection for remote communication |

| Buttons | Description |
|---------|---|
| OPEN | Open the door. |
| ↑ | Scroll the menu and increase of selected values. |
| ↓ | Scroll the menu and reduction of selected values. |
| ENTER | Button to select the menu and save the selected data. |
| ESC | Exit the menu. |


5.4 ELECTRICAL CONNECTION OF FUNCTION SELECTOR

Connect the 0-1-H-L terminals of the function selector, by cable (not supplied by us), to the 0-1-H-L terminals of the electronic control.

Note: for lengths over 10 m, use a cable with 2 twisted-pairs.


After connecting, the function selector is working. If you want to limit the use only by authorized personnel, use proximity badges (13,56MHz ISO15693 and ISO14443 Mifare) or numeric code (max 50 badges and codes).

The function selector allows the following settings.



| Symbol | Description |
|---------------------|---|
| | OPEN DOOR When selected, the symbol lights up, the door is permanently open. Note: the leaves can still be handled manually. |
| | AUTOMATIC BI-DIRECTIONAL OPERATION When selected, the symbol lights up, the door works automatic in bidirectional mode. RESET Select the symbol for 5 seconds, the automation performs the self-test and the automatic learning. |
| | CLOSED DOOR When selected, the door is permanently closed. Note: using the menu SEL > DLAY you can adjust the delay time to close the door. MANUAL OPERATION Select the symbol for 3 seconds, the symbol flashes and the door can be moved manually. |
| | AUTOMATIC PARTIAL OPERATION In the case of a door with 2 automations, when selected, the symbol lights and allows the automatic operation of only one leaf. |
| | AUTOMATIC ONE-WAY OPERATION When selected, the symbol lights up and automatic operation of the door is in one-way mode. |
| | FUNCTION SELECTOR IS NOT ACTIVE The symbol lights up when the function selector is not active. To activate the temporary operation of the function selector is necessary to approach the badge to the NFC symbol (FSD1), or enter the code (FSD4), or select for 3 seconds the logo. |
| | ACTIVATION OF THE FUNCTION SELECTOR Select the logo for 3 seconds (the lock symbol light off), the function selector is activated for 10 seconds. Expired the time the function selector switches off (the lock symbol lights up). |
| 1 2 3 4 5 | FSD1 - Authorized activation of function selector by badge. Approach the badge to the NFC symbol (the lock symbol light off), the function selector is activated for 10 seconds. Expired the time the function selector switches off (the lock symbol lights up). FSD4 - Authorized activation of function selector by numeric code. Press the logo, enter the code (maximum 5 numbers), press the logo for confirmation, (the lock symbol light off), the function selector is activated for 10 seconds. Expired the time the function selector switches off (the lock symbol lights up). |
| | BATTERY SIGNAL Battery symbol off = the door is operating with the mains supply Battery symbol on = the door is operating with battery power Battery symbol flashing = the battery is low or disconnected |
| | INFORMATION SIGNAL Information symbol on = it is necessary to perform the ordinary maintenance of the door. Information symbol flashing = shows the presence of alarms: - 1 flash = failure of electronic control or locking device; - 2 flashes = mechanical failure; - 3 flashes = failure of sensor safety test; - 4 flashes = motor overtemperature. |

5.5 ELECTRICAL CONNECTION OF OPENING SENSOR



Connect the sensor, using the supplied cable to the terminals of the electronic control as follows:

| | 5CB11 | OS1 (PrimeMotionB), OS2 (PrimeMotionC) | Notes |
|---------|---------|--|-------|
| OPENING | 0 | White | |
| | 1 | Brown | |
| | 1 | Yellow | |
| | 3A (3B) | Green | |


For more information, check the installation manual of the sensor.

5.6 ELECTRICAL CONNECTION OF SAFETY SENSOR

The safety sensors should be installed directly on the leaf of the door, and protect both the opening and the closing of the swing door.


To simplify the installation of the safety sensors, you can choose one of the following two options.

- OPTION 1: Connect the 2 sensors to each other, using the supplied cable. Connect only one of the 2 sensors to the electronic control terminals, as shown below.



| 5CB11 | | SD3 (4SAFE ON SW) | SD4 (FLATSCAN SW) | 5CB11 | | SD3 (4SAFE ON SW) | SD4 (FLATSCAN SW) |
|--------|----|-------------------|-------------------|--------|----|-------------------|-------------------|
| SAFETY | 0 | | | SAFETY | 0 | Brown | Brown |
| | | | | | | Blue | Blue |
| | 1 | Yellow | Yellow | | 1 | Green | Green |
| | | | | | | Pink | Pink |
| | 6A | White (DIP1=ON) | White (DIP1=ON) | | 8A | Purple (DIP1=OFF) | Grey (DIP1=OFF) |
| | 41 | | | | 41 | Red | Red |


- OPTION 2: Connect each sensor to the electronic control terminals, as shown below.




| 5CB11 | | SD3 (4SAFE ON SW) | SD4 (FLATSCAN SW) | 5CB11 | | SD3 (4SAFE ON SW) | SD4 (FLATSCAN SW) |
|--------|----|-------------------|-------------------|--------|----|-------------------|-------------------|
| SAFETY | 0 | Brown | Brown | SAFETY | 0 | Brown | Brown |
| | | Blue | Blue | | | Blue | Blue |
| | 1 | Green | Green | | 1 | Green | Green |
| | | Yellow | Yellow | | | Pink | Pink |
| | 6A | White (DIP1=ON) | White (DIP1=ON) | | 8A | Purple (DIP1=OFF) | Grey (DIP1=OFF) |
| | 41 | Red | Red | | 41 | Red | Red |

For more information, check the installation manual of the sensor.

SD3 (4SAFE ON SW)



SD4 (FLATSCAN SW)



5.7 ELECTRICAL CONNECTION OF A DOOR WITH 2 LEAVES

To coordinate the operation of two automatic swing doors with the closing overlap of the leaves (see figure), procedures as follows.



Using a 3-wire cable (1-H-L), connect the 2 automations MASTER-SLAVE, as shown in the figure.

Using the menu of the electronic control, set: ADV> SYNC> MST1 on MASTER automation and ADV> SYNC> SLV1 on SLAVE automation.

Connect the opening sensors as described in chapter 5.5 and connect the safety sensors as described in chapter 5.6.

If desired, connect the function selector, as shown in the figure.

Note: the partial opening of only one leaf is referred to the MASTER automation.



5.8. ELECTRICAL CONNECTIONS OF ELECTRIC LOCK

Automations for swing doors are compatible with most of the electric locks available in the market. Verify that power supply of the electric lock is 12Vdc (1 A max) or 24Vdc (0,5 A max).


- Connect the electric lock to terminals LK + and –LK of the electronic control.
- Set the electric lock power supply, using menu: ADV > LKPW > 12Vdc or 24Vdc.
- Set the type of electric lock operation, using menu: ADV > ELLK > LOCK or SAFE/AUTO.
- Set the operating time of the electric lock, using menu: ADV > TRLK > from 0,5 to 5,0 seconds.
- Set the start of the door opening delay time, using menu: ADV > TALK > from 0,5 to 5,0 seconds.

In the figure are shown the timing of the electric lock operation:

A = start of opening pulse and electric lock power supply on/off,

B = start of door opening,

C = end of electric lock power supply on/off.



6. ELECTRONIC CONTROL ADJUSTEMENT

The electronic control has 4 buttons and 4 alphanumeric displays to set all the necessary adjustments.

After turning on the electronic control, the display shows the word "MENU". The operation of the four keys are indicated in the table.

| Keys | Description | |
|-------|--|--|
| ENTER | Select button, each time you press the button you enter on the selected parameter. Save button, pressing for 1 seconds you "SAVE" the selected value. MENU = Main parameters menu ADV = Advanced parameters menu SEL = Function selector menu MEM = Memory management menu INFO = Information and diagnostics menu | |
| ESC | Exit button, exit from all the parameter or exit from the menu. | |
| ↑ | Scroll button, each press selects a menu item or increases the value of the selected item. | |
| ↓ | Scroll button, each press selects a menu item or reduces the value of the selected item. | |
| ↑ + ↓ | To turn upside down the display, press the two scroll buttons simultaneously for 3 seconds. | |

6.1 MENU (BASIC SETTINGS MENU)

Using the buttons ↑ and ↓ choose MENU, press ENTER to select and adjust the following parameters.

| Display | Description | Factory settings |
|-----------------------------|--|------------------|
| DOOR DOOR TYPE | Setting the automation type. Choose between the following values: 80S = SW80S automation 80S1 = SW80S1 automation | 80S1 |
| ARM ARM TYPE | Setting the type of arm. Choose between the following values: SA = sliding arm to pull SA1 = sliding arm to push AA = articulated arm to push | SA |
| VOP OPENING SPEED | Opening speed setting. Choose between the minimum and maximum: minimum value = 15 deg/s maximum value = 70 deg/s | 50 |
| VCL CLOSING SPEED | Closing speed setting. Choose between the minimum and maximum: minimum value = 15 deg/s maximum value = 50 deg/s | 30 |
| TAC CLOSING TIME | Open door time setting. Choose between the minimum and maximum: NO = the door is always open minimum value = 1 s maximum value = 30 s | 1 |
| PUSH MOTOR POWER | Force setting. Choose between the minimum and maximum: minimum value = 1 maximum value = 10 | 10 |
| LEAF DOOR WEIGHT | Setting the weight of the door. Choose between the following values: MIN = light door MED = medium door MAX = heavy door | MED |
| RAMP ACCELERATION | Set the door acceleration. Choose between the following values: SLOW = slow acceleration MED = medium acceleration FAST = fast acceleration | MED |
| BTMD BATTERY MODE | Setting operation of battery power device, in absence of electricity. Choose between the following values: NO = battery not connected EMER = emergency open CONT = continuation of normal operation of the door, with last cycle of opening Note: the number of operations with battery, depends on the efficiency of the battery, the weight of the doors and the present friction. | NO |

6.2 ADV (ADVANCED PARAMETERS MENU)

Using the buttons ↑ and ↓ select ADV, press ENTER to select and adjust the following parameters.

| Display | Description | Factory settings |
|--|--|------------------|
| 8AEX 8A- EXCLUSION | Exclusion of the operation of the sensor closing safety. Choose between the minimum and maximum values: minimum value = 0% maximum value = 50% | 0 |
| 6AEX 6A- EXCLUSION | Exclusion of the operation of the sensor opening safety. Choose between the minimum and maximum values: minimum value = 0% maximum value = 50% | 0 |
| ST6A 6A-SETTING | Operation of 6A safety command, after the door stop. Choose between the following values: CLOS = automatic closing of the door OPEN = continues the opening of the door | CLOS |
| ELLK LOCK OPERATION TYPE | Selecting the electric lock. Choose between the following values: NO = electric lock not connected LOCK = standard electric lock (security operation) SAFE = electromagnet (safety operation) AUTO = electromagnet (operation matched to the function selector) OPEN = electromagnet for open door | NO |
| LKPW LOCK POWER SUPPLY | Power supply electric lock. Choose between the following values: 12 = 12V electric lock 24 = 24V electric lock | 12 |
| TALK LOCK ADVANCE TIME | Time advance operating electric lock. Choose between the minimum and maximum values: minimum value = 0 s maximum value = 5 s | 0.5 |
| TRLK LOCK OPERATION TIME | Operating time of the electric lock. Choose between the minimum and maximum values: minimum value = 0,5 s maximum value = 5 s | 0.5 |
| LKSH LOCK HOOKING | Setting of closing push for hooking the electric lock. Choose between the following values: NO = no push MIN = light push MED = medium push MAX = heavy push | NO |
| PUCL PUSH DOOR CLOSED | Setting the push on the closed mechanical stop. Choose between the following values: NO = no push MIN = light push MED = medium push MAX = heavy push XMAX = very heavy push | NO |
| PIPP PUSH DOOR OPEN | Setting of the opening push. Choose between the following values: NO = no push YES = push enabled (disabled with ANG) | NO |
| HOLD HOLD DOOR OPEN | Setting the push of keeping the door open. Choose between the following values: NO = no push MIN = light push MED = medium push MAX = heavy push | MED |
| HAND MANUAL OPERATION | Manual operation of the door in power-assisted mode or with push opening. Choose between the following values: NO = disabled manual operation power-assisted MIN = minimum manual operation power-assisted (Note: the safety devices are disabled) MAX = maximum manual operation power-assisted (Note: the safety devices are disabled) PUGO = push opening enabled | PUGO |

| Display | Description | Factory settings |
|--|---|------------------|
| ANG OPENING ANGLE | Selecting of the door opening angle. Choose between the following values: NO = the door opens up to the mechanical opening stop 50 ... 240 = the door opens up to the selected angle (minimum angle = 50) Note: the value indicated refers to the arm angle and not to the door angle | NO |
| TAKO KO-CLOSING TIME | Open door time setting, after the 1-G1/G2/G3/G4 command (see menu settings: ADV > STG1/STG2/STG3/STG4 = KO/KO2). Choose between the minimum and maximum: minimum value = 1 s maximum value = 30 s NO = the door is always open NO = see MENU > TAC | NO |
| MOT MOTOR CIRCUIT | Setting the manual friction of the door, by means of the electrical connection of the motor windings. Choose between the following values: OC = manual door opening without friction (motor with open circuit windings) SC = manual door opening with friction (motor with short-circuit windings) | OC |
| T41 SAFETY TEST | Enable test for safety devices (in accordance with EN 16005). Choose between the following values: NO = test disabled YES = test enable | YES |
| SYNC DOOR SYNCHRO- NIZATION | Door with 2 leaves, setting of master-slave synchronization. Choose between the following values: NO = no synchronization (door with 1 leaf) MST1 = automation MASTER which opens first SLV1 = automation SLAVE which closes first MST2 = external automation MASTER which opens first (see menu: ADV > INK > EXT) SLV2 = external automation SLAVE which closes first (see menu: ADV > INK > EXT) | NO |
| SDLY DOOR DELAY | Door with 2 leaves, setting of delay of movement between Master-Slave. Choose between the following values: NO = leaves without overlap MIN = minimum delay MED = medium delay MAX = maximum delay | MED |
| INK INTER-LOCKED DOOR | Interlocked operation of two automatic doors, the opening of a door is permitted only when the other door is closed. Choose between the following values. NO = no interlock INT = internal door EXT = external door | NO |
| ID IDENTIFICATION NUMBER | If several automations are connected to the network via the 1-H-L terminals, they must have different identification numbers. Choose between the following values: NO = no network 0 / 1 / 2 / 3 / 4 / 5 / 6 / 7 / 8 / 9 / 10 / 11 / 12 / 13 / 14 | NO |
| SPR SPRING OPERATION | Select the type of spring operation. CLOS = the spring closes the door OPEN = the spring opens the door | CLOS |

| Display | Description | Factory settings |
|--|--|------------------|
| STG1 G1-SETTING STG2 G2-SETTING | <p>INPUT COMMANDS BETWEEN 1-G1 AND 1-G2 TERMINALS. Choose between the following values.</p> <p>NO = no function KO = opening command KO2 = semi-priority opening command (not active with function selector in closed door) KC = closing command VOPN = N.O. opening limit-switch STEP = Step-by-step contact N.O. The closing of the contact performs in sequence the opening (disabled automatic closure) and the closing of the door. SAM = Automatic setting command of function selector. The closing of the contact changes the function selector mode (see menu: SEL > SAM1 and SEL > SAM2). EMER = Emergency opening contact N.C. The opening of the 1-G1 contact opens the door. RSET = reset command CAB = Step-by-step contact N.O. The closing of the contact performs in sequence the closing of the door (disabling 3A/3B terminals, enabling the signaling for occupied cabin) and the opening of the door (enabling 3A/3B terminals, disabling the signaling for occupied cabin). INKE = Interlocked operation exclusion command between two doors (see menu: ADV > INK). PART = Opening command for the MASTER door only (see menu: ADV > SYNC).</p> <p>OUTPUT SIGNALS BETWEEN 0-G1 AND 0-G2 TERMINALS (12Vdc 20mA). Choose between the following values.</p> <p>BELL = The output is activated for 3 seconds when people enter the store (through the sequential activation of the contacts: 1-3B and 1-3A). SERV = The output is activated when the door reaches the number of maintenance cycles, set using the menu: INFO > SERV. WARN = The output is activated when at least one warning remains active for 5 minutes. For remove the alarm signal make a reset or turn off the power supply. CLOS = The output is activated when the door is closed OPEN = The output is activated when the door is open AIR = The output is activated when the door is not closed LAMP = The output is activated when the door is moving CABS = Signaling of the occupied cabin (see menu: ADV > STG2 > CAB) INK = Red traffic light signaling for interlocked doors (see menu: ADV > INK) PWOF = The output is activated in the absence of power supply (W128) HAND = The output is activated when the door is opened by hand</p> | NO |
| STG3 G2-SETTING STG4 G4-SETTING | <p>INPUT COMMANDS BETWEEN 1-G3 AND 1-G4 TERMINALS. Choose between the following values.</p> <p>NO = no function KO = opening command KO2 = semi-priority opening command (not active with function selector in closed door) KC = closing command VOPN = N.O. opening limit-switch STEP = Step-by-step contact N.O. The closing of the contact performs in sequence the opening (disabled automatic closure) and the closing of the door. SAM = Automatic setting command of function selector. The closing of the contact changes the function selector mode (see menu: SEL > SAM1 and SEL > SAM2). EMER = Emergency opening contact N.C. The opening of the 1-G2 contact opens the door. RSET = reset command CAB = Step-by-step contact N.O. The closing of the contact performs in sequence the closing of the door (disabling 3A/3B terminals, enabling the signaling for occupied cabin) and the opening of the door (enabling 3A/3B terminals, disabling the signaling for occupied cabin). INKE = Interlocked operation exclusion command between two doors (see menu: ADV > INK). PART = Opening command for the MASTER door only (see menu: ADV > SYNC).</p> | NO |

6.3 SEL (FUNCTION SELECTOR MENU)

Using the buttons ↑ and ↓ select SEL, press ENTER to select and adjust the following parameters.

| Display | Description | Factory settings |
|--|--|------------------|
| MODE SELECTOR MODE | Displaying of operating mode of function selector device. Choose between the following values: NO = no mode OPEN = open door AUTO = automatic bi-directional operation CLOS = closed door 1D = automatic one-way operation PA = automatic partial operation 1DPA = automatic one-way operation and partial HAND = manual operation | NO |
| SECL SELECTOR LOCK | How to activate the function selector. Choose between the following values: NO = function selector always accessible LOGO = function selector accessible by selecting the logo for 3 seconds TAG = function selector accessible with badge and numeric code | NO |
| DLAY DELAY CLOSED DOOR | Setting delay time function closed door. Choose between the minimum and maximum values: minimum value = 1 s maximum value = 5 min | 1 |
| TMEM TAG MEMORISE | Saving procedure of badge and numeric code for function selector. Choose between the following values. NO = no saving SMOD = Saving badge and numeric code for activation of the function selector: - press the ENTER button for 1 second, the display shows REDY, FSD1 - approach the badge to the function selector (in front of the NFC symbol), the display shows the badge code, FSD4 - press the logo, enter the code (from 1 to 5 numbers), press the logo for confirmation, the display shows the numeric code (Note: the numeric code can be stored only if SECL=TAG), - wait for 20 seconds or press the ESC button. OPEN = Saving badge and numeric code for activation of priority opening: proceed as SMOD Note: if the badge and the numeric code is not recognized the display shows the message UNKN, or if the badge and the numeric code is already stored will show the message NOK. You can store a total maximum of 50 badges and numeric codes. APP = Saving phone for activation of the FACE SRC App - press the ENTER button for 1 second, the display shows REDY, FSD1 - approach the phone to the function selector, in front of the NFC symbol. Note: Look for the most suitable position. | NO |
| TMAS TAG MASTER | It is possible to create master badge and master numeric code that allows the saving of the badges and the numeric codes, without the use of the menu. Choose from the following values. NO = no saving MMOD = creation of the master badge and master numeric code to saving badges and numeric codes for function selector activation: proceed as SMOD. MOPE = creation of the master badge and master numeric code to saving the badges and numeric codes of opening priority: proceed as SMOD. Note: if the badge and the numeric code is not recognized the display shows the message UNKN, or if the badge and the numeric code is already stored will show the message NOK. FSD1 - The use of the master badge is the following: - approach the master badge to the function selector (in front of the NFC symbol), the buzzer emits 2 beeps at the beginning of the storage procedure, - approach the badges, that you want to store, one at a time, to the function selector (in front of the NFC symbol), the buzzer emits 1 beep of confirmation storage, - wait for 20 seconds, the buzzer emits 2 beeps at the end of the storage procedure. FSD4 - The use of the master numeric code is the following: - press the logo, enter the master numeric code, press the logo for confirmation, the buzzer emits 2 beeps at the beginning of the storage procedure, - press the logo, enter the new code (from 1 to 5 numbers), press the logo for confirmation,, the buzzer emits 1 beep of confirmation storage, - wait for 20 seconds, the buzzer emits 2 beeps at the end of the storage procedure. Note: if the badge and the numeric code is not stored, the buzzer emits no beeps. | NO |

| Display | Description | Factory settings |
|--|---|------------------|
| TDEL TAG DELETE | <p>Cancellation procedure of badge and numeric code. Choose between the following values.</p> <p>NO = no cancellation YES = badge and numeric code cancellation</p> <p>- press the ENTER button for 1 second, the display shows REDY, FSD1 - approach the badge to the function selector (in front of the NFC symbol), the display shows the badge code, FSD4 - press the logo, enter the code (from 1 to 5 numbers), press the logo for confirmation, the display shows the numeric code.</p> <p>- wait for 20 seconds or press the ESC button.</p> <p>Note: if the badge and the numeric code is not recognized the display shows the message UNKN.</p> | NO |
| TERA TAG TOTAL ERASE | <p>How to erase all stored badges and numeric codes. Choose between the following values:</p> <p>NO = no erase YES = cancellation of all badges and numeric codes</p> | NO |
| SAM1 SELECTOR AUTOMATIC MODE | <p>Changing the function selector function when the 1-G1/G2/G3/G4 contact closes.</p> <p>Activate the SAM mode using the menu ADV > STG1/STG2/STG3/STG4 > SAM.</p> <p>Connect the contact of a clock to 1-G1/G2/G3/G4 terminals, and choose between the following values:</p> <p>OPEN = open door AUTO = automatic bi-directional operation CLOS = closed door 1D = automatic one-way operation HAND = manual operation</p> | CLOS |
| SAM2 SELECTOR AUTOMATIC MODE | <p>Changing the function selector function when the 1-G1/G2/G3/G4 contact opens</p> <p>Activate the SAM mode using the menu ADV > STG1/STG2/STG3/STG4 > SAM.</p> <p>Connect the contact of a clock to 1-G1/G2/G3/G4 terminals, and choose between the following values:</p> <p>OPEN = open door AUTO = automatic bi-directional operation CLOS = closed door 1D = automatic one-way operation HAND = manual operation</p> | CLOS |
| FW FIRMWARE UPGRADE | <p>Programming procedure of function selector.</p> <p>Insert the USB memory in the electronic control.</p> <p>From this menu, choose the firmware version you want.</p> <p>Press ENTER until it starts the programming procedure that lasts about 30 seconds (the display shows "WAIT •••"), at the end the display shows "SAVE".</p> <p>After the procedure, remove the USB memory from the electronic control and store it for future use.</p> <p>Note: in the case of programming error or missing firmware (W103), proceed as follows: disconnect the power supply, insert the USB memory, give power supply, and repeat the programming procedure from this menu.</p> | ---- |
| VER VERSION | <p>Displaying the firmware version of function selector (eg = 0435).</p> | ---- |
| TIN TAG INPUT | <p>You can upload the badges and numeric codes used in another automation, already stored in the USB memory. Choose between the following values:</p> <p>NO = no upload YES = upload the badges and numeric codes from the USB memory</p> | NO |
| TOUT TAG OUTPUT | <p>You can save the stored badges and numeric codes in the USB memory. Choose between the following values:</p> <p>NO = no save YES = save the stored badges and numeric codes in the USB memory</p> | NO |

6.4 MEM (MEMORY MANAGEMENT MENU)

























Using the buttons ↑ and ↓ select MEM, press ENTER to select and adjust the following parameters.

| Display | Description | Factory settings |
|------------------------------------|--|------------------|
| FSET FACTORY SETTINGS | Restore all settings to factory defaults. Choose between the following values: NO = no restore. YES = restore to factory settings. | NO |
| FW FIRMWARE UPGRADE | Programming procedure of electronic control. Insert the USB memory in the electronic control. From this menu, choose the firmware version you want. Press ENTER until it starts the programming procedure that lasts about 30 seconds (the display shows "WAIT ••••"), at the end the display shows "SAVE". After the procedure, remove the USB memory from the electronic control and store it for future use. Note: in the case of programming error or missing firmware (W100), proceed as follows: disconnect the power supply, insert the USB memory, give power supply, the programming procedure starts automatically. | ---- |
| SIN SETTING INPUT | You can upload the menu settings used in another automation, already stored in the USB memory. Choose between the following values: NO = no upload YES = upload the menu settings from the USB memory | NO |
| SOUT SETTING OUTPUT | You can save the menu settings of automation in use, in the USB memory. Choose between the following values: NO = no save YES = save the menu settings of automation in the USB memory | NO |

6.5 INFO (INFORMATION AND DIAGNOSTICS MENU)

Using the buttons ↑ and ↓ select INFO, press ENTER to select and adjust the following parameters.

| Display | Description | Factory settings |
|----------------------------------|--|------------------|
| VER VERSION | Displaying the firmware version of electronic control (eg = 0120). | ---- |
| CYCL CYCLES | Shows the number of cycles of the door (1 = 1.000 cycles, 9000 = 9.000.000 cycles). | 0000 |
| SERV SERVICE SIGNAL | Enabling the signaling of routine maintenance of the door. NO = no signaling 1 = 1.000 cycles / 9000 = 9.000.000 cycles | 0000 |
| LOG INFO OUTPUT | You can save the following information in the USB memory (sw80_log.txt): the last 20 warnings, the menu settings, and the electronic devices connected to automation. Choose between the following values: NO = no save YES = save the information in the USB memory | NO |
| WARN WARNING LIST | Displaying of the last 10 warnings (the warning number 0 is the last): 0.xxx / 1.xxx / 2.xxx / 3.xxx / 4.xxx / 5.xxx / 6.xxx / 7.xxx / 8.xxx / 9.xxx | 0.--- |

| DISPLAY | SEL | FLASH | WARNING | CHECK |
|---------|---|-------|--------------------------------------|---|
| W001 |  | 1 | Encoder error | Check encoder connection |
| W002 |  | 1 | Motor short circuit | Check the connection of the motor |
| W003 |  | 1 | Motor control error | Electronic control failure |
| W010 |  | 2 | Direction reversed | Check the presence of obstacles |
| W011 |  | 2 | Running too long | Check the connection between the motor and leaf |
| W012 |  | 2 | Running too short | Check the presence of obstacles |
| W013 |  | 2 | Overrun | Check the mechanical stops |
| W100 | - | - | Programming error | Repeat the programming procedure in MEM > FW menu |
| W103 | - | - | Programming error Selector | Repeat the programming procedure in SEL > FW menu |
| W127 | - | - | Automation reset | The automation performs a self-test |
| W128 |  | on | No power supply | Check the power supply |
| W129 |  | 1 | No battery | Check the battery connection |
| W130 |  | 1 | Low Battery | Replace or recharge the battery |
| W140 |  | 3 | 6A safety test failure | Check the safety sensor connection |
| W142 |  | 3 | 8A safety test failure | Check the safety sensor connection |
| W145 |  | 4 | Motor overtemperature (first step) | The door reduces the speed |
| W146 |  | 4 | Motor overtemperature (second step) | The door stops |
| W150 |  | 2 | Obstacle in opening | Check the presence of obstacles |
| W151 |  | 2 | Obstacle in closing | Check the presence of obstacles |
| W152 |  | 2 | Door locked open | Check the presence of locks |
| W153 |  | 2 | Door locked closed | Check the presence of locks |
| W156 |  | 2 | Door moved manually | Wait about 5 seconds |
| W160 |  | 1 | Synchronization error | Check the ADV > SYNC and the ADV > INK menu |
| W256 |  | - | Power on | - |
| W257 |  | - | Firmware update | - |
| W320 |  | on | Signaling of maintenance | Check the INFO > SERV menu |
| W330 |  | 1 | Tuning between motor and electronics | Wait about 3-30 seconds |

7. START-UP PROCEDURE OF THE AUTOMATIC SWING DOOR

7.1 Preliminary checks.

At the end of the installation, move the doors manually and make sure that operation is smooth and without friction. Check the solidity of the structure and the proper attachment of all the screws. Check the correctness of all electrical connections. Make sure you have installed the mechanical stop of the open door.

Before connecting any security devices, leave the jumper on terminals safety (41-6A, 41-8A).

7.2 Giving power supply and connect the battery, if present.

Note: every time you switch on the automation performs a self-test (from 3 to 30 seconds). The first opening and closing cycle is at low speed to allow the automatic learning.

To ensure that the electronic control has the factory settings, restore via the menu:

MEM> FSET> YES (confirm by pressing ENTER for 1 second).

Select the type of automation via the menu: MENU > DOOR > 80S / 80S1.

If the door is with articulated arm to push, set as follow: MENU > ARM > AA.

If the door is with sliding arm to push, set as follow: MENU > ARM > SA1.

Perform the menu settings as described in Chapter 6. Use OPEN button to perform the opening door, and verify the correct operation of the door.

Note: the automation automatically detects any obstacles during the closing movement (reversal movement) and opening (stopping movement).

If present, connect the electric lock of the door to the terminals (-LK \ +LK) of electronic control, and make the settings available in the ADV menu. described in Chapter 5.8.


7.3 Connect one at a time, control and safety devices to protect the opening and closing cycle of the door, as described in Chapter 5.6, and verify proper operations.

Note: verify that the opening access is properly protected by safety sensors, in accordance with the requirements of the European standard EN16005 (annex C), or make speed adjustments in accordance with European standards EN16005 (Annex G), as shown in chapter 8.

7.4 At the end of the automation starting, deliver to the owner the user instructions, including all warnings and information necessary to maintain the security and functionality of the automatic door.

Automations are feature of label containing the required information by European standards EN16005 and EN60335-2-103.

Note: the manufacturer of the automatic swing door have to add his own label identifying the installation.




| | |
|--|---|
| FACE S.r.l. | www.facespa.it |
| Viale delle Industrie,74 - 31030 Dosson di Casier (TV) | |
| Type: SW80S | Standard: EN16005 |
| DRIVE UNIT FOR SWING DOOR | |
| Input: 100-240V 50/60Hz Power: 70W | |
| Load: 40Nm S3: 100% | |
| Tmin: -15°C Tmax: +50°C IP20 | |
| SW80S | s/n: 1903 0001 Year: 2019 |
| CE |  |
| made in Italy 0070419030001 | |

8. ADJUSTMENT OF THE KINETIC ENERGY OF THE DOOR

To reduce the kinetic energy of the door in area B not protected by safety sensors, make the following adjustments.

Adjust the opening speed (VOP) so as to open the door (from 0° to 80°) at the times indicated in the table.

Adjust the closing speed (VCL) so as to close the door (from 90° to 10°) at the times indicated in the table.



| Lm [m] | Time [s] | | | | | | | | | | | |
|--------|----------|------|------|------|------|------|------|------|------|------|------|--|
| | 1,0 | 1,5 | 2,0 | 2,5 | 3,0 | 3,5 | 4,0 | 4,5 | 5,0 | 5,5 | 6,0 | |
| | B [m] | | | | | | | | | | | |
| | 0,16 | 0,24 | 0,32 | 0,40 | 0,48 | 0,56 | 0,64 | 0,72 | 0,80 | 0,88 | 0,95 | |
| A [m] | | | | | | | | | | | | |
| 0,7 | 0,54 | 0,46 | 0,38 | 0,30 | 0,22 | 0,14 | 0,06 | - | - | - | - | |
| 0,8 | 0,64 | 0,56 | 0,48 | 0,40 | 0,32 | 0,24 | 0,16 | 0,08 | - | - | - | |
| 0,9 | 0,74 | 0,66 | 0,58 | 0,50 | 0,42 | 0,34 | 0,26 | 0,18 | 0,10 | 0,02 | - | |
| 1,0 | 0,84 | 0,76 | 0,68 | 0,60 | 0,52 | 0,44 | 0,36 | 0,28 | 0,20 | 0,12 | 0,05 | |
| 1,1 | 0,94 | 0,86 | 0,78 | 0,70 | 0,62 | 0,54 | 0,46 | 0,38 | 0,30 | 0,22 | 0,15 | |
| 1,2 | 1,04 | 0,96 | 0,88 | 0,80 | 0,72 | 0,64 | 0,56 | 0,48 | 0,40 | 0,32 | 0,25 | |
| 1,3 | 1,14 | 1,06 | 0,98 | 0,90 | 0,82 | 0,74 | 0,66 | 0,58 | 0,50 | 0,42 | 0,35 | |
| 1,4 | 1,24 | 1,16 | 1,08 | 1,00 | 0,92 | 0,84 | 0,76 | 0,68 | 0,60 | 0,52 | 0,45 | |
| 1,5 | 1,34 | 1,26 | 1,18 | 1,10 | 1,02 | 0,94 | 0,86 | 0,78 | 0,70 | 0,62 | 0,55 | |

9. TROUBLESHOOTING

In addition to the following list of possible problems, there are warnings provided by the display, as described in chapter 6.5.

| Problem | Possible causes | Remedy |
|--|--|--|
| The automation does not open or close. | No power supply (display off). | Check the power supply. |
| | Short circuited external accessories. | Disconnect all accessories from terminals 0-1 and reconnect them one at a time (check for voltage 12V). |
| | The door is locked by bolts and locks. | Check the freely move of the doors |
| The automation does not perform the functions set. | Function selector incorrectly set. | Check and correct the settings of the function selector. |
| | Control devices or safety always activated. | Disconnect devices from the terminal and verify the operation of the door. |
| The movement of the doors isn't linear, or reverse the movement for no reason. | The automation does not successfully perform the automatic learning. | Perform a reset or power off and power on the automation. |
| The automation opens but does not close | Anomalies during the safety devices test. | Jumper contacts one at a time 41 -6A , 41 - 8A. |
| | The opening devices are activated. | Verify that the opening sensors are not subject to vibration , do not perform false detections or the presence of moving objects in the field of action. |
| | The automatic closing doesn't work. | Check the settings of the function selector . |
| Safety devices not activating. | Incorrect connections between the safety devices and electronic control. | Check that the safety contacts of the devices are properly connected to the terminal blocks and the relative jumpers have been removed. |
| The automation opens by itself. | The opening and safety devices are unstable or detect moving bodies | Verify that the opening sensors are not subject to vibration , do not perform false detections or the presence of moving bodies in the field of action. |

10. AUTOMATIC SWING DOOR ROUTINE MAINTENANCE PLAN

To ensure proper operation and safe use of the automatic swing door, as required by European standard EN16005, the owner has to perform routine maintenance by qualified personnel.

Except for routine cleaning of the door, the responsibility of the owner, all maintenance and repair work must be carried out by qualified personnel.

The following table lists tasks related to routine maintenance, and the frequency of intervention related to an automatic swing door operation with standard conditions. In the case of more severe operating conditions, or in the case of sporadic use of the automatic swing door, the frequency of maintenance can be consistently adequate.

| Task | Frequency |
|---|--|
| Remove the power supply, open the automation and perform the following checks and adjustments. - Check all screws fastening of components within the automation. - Check the state of wear of the hinges (if necessary replace them). - Verify correct mounting of the arm on the door. - Check the correct force of the closing spring. - If present, verify proper engagement of the electric lock. | Every 6 months or every 200.000 cycles. |
| Connect the power supply and perform the following checks and adjustments. - Check the correct operation of the control devices and safety. - Check the detection area of the security sensors complies with the requirements of the European standard EN16005. - If present, verify the correct operation of the electric lock. - If present, verify the correct operation of the battery power device (if necessary replace the battery). | Every 6 months or every 200.000 cycles. Note: the EN16005 European standard requires the verification of the safety functions of the automation and of the safety devices at least once a year. |

All maintenance, replacement, repair, update, etc.. must be written into the proof book, as required by European standard EN16005, and delivered to the owner of the automatic swing door.

For repairs or replacements of products, original spare parts must be used.

10.1 DISPOSAL OF PRODUCTS



The packaging materials (cardboard, plastic, and so on) should be disposed of as solid household waste, and simply separated from other waste for recycling.

Our products are made of various materials. Most of these (aluminum, plastic, iron, electrical cables) are classified as solid household waste. They can be recycled by separating them before dumping at authorized city plants.

Whereas other components (control boards, batteries, and so on) may contain hazardous pollutants.

These must therefore be disposed of by authorized, certified professional services.

Before disposing, it is always advisable to check with the specific laws that apply in your area.

DO NOT DISPOSE IN THE ENVIRONMENT.

FACE S.r.l.

Viale delle Industrie, 74 - 31030 Dosson di Casier (TV) – Italy

Fax +39 0422 380414 \ Phone +39 0422 492730

E-mail: info@facespa.it \ www.facespa.it

