

01244 287050 01244 289175 e: sales@venalink.co.uk www.venalink.co.uk Unit 46, First Av, Zone 2, Deeside Ind. Park CH5 2NU

HOW TO PRODUCE THE PERFECT SEAL - QUBE 2PSA

















1. CREASE

- Fold the right panel over to cover the centre panel of the card
- Crease the folded edge using your fingers

2. **ALIGN & PEEL**

- Open out the card
- Place the right panel over the foam template & line up the holes
- Peel off the cover paper to reveal the adhesive on the middle & right panels **IMPORTANT** - peel the backing paper
- from left to right Line up the blister with the card holes
- and place inside the card and template Smooth over the top of the blister with

FOLD & TURN 3.

yourhand

- Fold the left and centre panel over
- Rub over the back using your hand to prepare for sealing
- Turn the card 45 degrees clockwise from portrait to landscape









4. SEAL

- Using the roller, roll from bottom to top applying pressure
- Repeat this to cover the entire surface
- Ensure you roll right over the edges of the card
- Turn the card 90 degrees clockwise from landscape to portrait and repeat the above steps.