


416

INSTALLATION INSTRUCTIONS FOR BEST DOUBLED KEYED UNION CYLINDER


1. Prepare Door - Refer to lock manufacturers' specifications.

2. Prepare Cylinder.

- A. Looking into figure "8" hole, identify throw plug with drive pin on left side and "v" mark at top (Fig. 1).
- B. Rotate throw pins with mortise tool ED211 or screwdriver until they are 7 1/2 degrees from horizontal position (Fig. 1).
- C. Install core.
- D. Turn cylinder around and identify throw plug with drive pin on right side and "v" mark at top (Fig. 2).
- E. Rotate throw pins with mortise tool ED211 or screwdriver until they are 7-1/2 degrees from horizontal position (Fig. 2).
- F. Install core.




3. Install complete cylinder assembly with cores into lockset with cam positioned toward door hinges (Fig. 3). Tighten cylinder set screw.



4. With door open, check operation of lockset. Caution: If keying is different for inside and outside of door, be certain proper core is installed in proper side of cylinder.

ATTENTION: Locksets that secure both sides of door may cause delay during emergency exit and could be hazardous or even fatal.



BEST LOCK CORPORATION
INDIANAPOLIS, INDIANA 46250