

PLACE PIN HERE

PRECAST BULLETIN

ARMCON

CERTAINTY: IN CONCRETE

Don't Waste Pigment



Adding more pigment doesn't always mean more colour.

Usually an 8% powder colour/cement ratio is required.

Superplasticiser can aid pigment dispersion for brighter colours.

Keep the same water/cement ratio to ensure a consistent colour.

TECH TIP

Mixing equipment plays a crucial part in the dispersion of colour and will greatly affect the quality of the finished product. A good doser and mixing system are essential investments and will reduce your operating costs.

**For Help & Support Contact:
01625 856685**

www.armcon.com

sales@armcon.com