

SL3[®] Floating Turbo Dressing Instructions

In order to get the best and quickest results from your new SL3[®] Floating Turbo pads, they should be properly dressed before first use.

1. After mounting the red SL3[®] adapter on the appropriate grinder/polisher, firmly attach the Floating Turbo to the 3" - Center Hub, Hook & Loop backer and lock the backer into the red adapter.
2. Run the turbo, with water, against some concrete or the backside of a scrap of granite until the resin surface shine has been removed. This will expose the diamonds.
3. While the grinder is running, roll the abrasive up to round over the sharp outer edge of the pad. This step will need to be repeated as the pad wears down. Failure to round the edge will create half-moon scratches in the finished work piece.
4. Your new SL3[®] floating turbo is ready for use.