

RP 17035

COMPLIANCE SYSTEM REPLACEMENT

THIS REPLACEMENT BUSHING ELIMINATES THE NEED FOR ITEM #10 (2 BUSHINGS), ITEM #16 (1 BUSHING AND 2 SHACKLE PLATES) AND ITEM #17 (SPRING).

CAUTION - BOTH SIDES MUST BE CHANGED AT THE SAME TIME AS HANDLING CHARACTERISTICS ARE GREATLY IMPROVED.

INSTALLATION:

REMOVE AND DISCARD ITEMS 10, 16 AND 17.

INSTALL OUR REPLACEMENT BUSHING BY PRESSING IT INTO BRACKET #3 FROM THE FRONT SIDE (LARGE DIAMETER ON THE BUSHING TOWARD THE FRONT OF THE CAR). NOTE: MAKE SURE THE THIN OUTER SHELL OF THE OLD BUSHING HAS BEEN COMPLETELY REMOVED FROM THE BRACKET.

REINSTALL BRACKET #9 WITH BOLT #4 THROUGH THE NEW BUSHING. PUT THE WEIGHT OF THE VEHICLE ON THE WHEELS BEFORE FINAL TIGHTENING OF BOLT #4 AND THE BOLT AT THE INNER END OF THE LOWER CONTROL ARM.

TIGHTEN TO MANUFACTURER'S SPECIFICATIONS AND HAVE THE CAR ALIGNED BEFORE PUTTING IT BACK INTO SERVICE.

