





CERTAINTY: IN CONCRETE

SAFETY FIRST: Always remove keys and lock off power before carrying out any maintenance

FROST DAMAGE Protect your mixer

ALWAYS DRAIN IF THERE IS A RISK OF FREEZING



- 1. Shut off main water supply valve. There is no need to drain tank
- 2. Open the individual drain valves.
- 3. Use air-line to purge system (see image)
- 4. Leave the valves open until the machine is next operated
- 5. CHECK! Your admix system as it may also need draining

TECH TIP In freezing weather,

avoid leaving the machine loaded overnight

Learn how on You Tube

www.youtube.com/user/armcontechtips

SERVICE LINE : 01625 856 699 www.armcon.com service@armcon.com