


MARBURG MEDIUM BRAILLE CHART

For Sales, Service and Labels

Tel: 01279 427779

www.ditac.com



This chart shows the dot position to allow label sizing for use in Braille Embossers when set at default. Precise dimensions of cells and spacing are shown in millimeters in the diagram to the right.

Paper position in Embosser has to be set by the user to ensure correct start position.

Characters Per Line

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
0.25"	[Braille grid]																									[Braille grid]														
0.5"	[Braille grid]																									[Braille grid]														
0.75"	[Braille grid]																									[Braille grid]														
1"	[Braille grid]																									[Braille grid]														
1.25"	[Braille grid]																									[Braille grid]														
1.5"	[Braille grid]																									[Braille grid]														
1.75"	[Braille grid]																									[Braille grid]														
2"	[Braille grid]																									[Braille grid]														
2.25"	[Braille grid]																									[Braille grid]														
2.5"	[Braille grid]																									[Braille grid]														
2.75"	[Braille grid]																									[Braille grid]														
3"	[Braille grid]																									[Braille grid]														
3.25"	[Braille grid]																									[Braille grid]														
3.5"	[Braille grid]																									[Braille grid]														
3.75"	[Braille grid]																									[Braille grid]														
4"	[Braille grid]																									[Braille grid]														
	a			b			c			d			e			f			g			h			i			j			k			l			m			
	n			o			p			q			r			s			t			u			v			w			x			y			z			
	1		2		3		4		5		6		7		8		9		0																					