



ARMCON

CERTAINTY: IN CONCRETE

SAFETY FIRST: Always remove keys and lock off power before carrying out any maintenance

CHAIN RAILS support your conveyor

Top chain rails help support the conveyor when carrying the aggregate load

Chain rails help to provide thousands of meters of production, but they will wear and need checking

Left unchecked, chain rails will waste and thin in size, causing serious problems if not replaced

New chain rails start life at 19mm in size







TECH TIP

Check your chain rails as part of your bi-annual, complete mixer service

Learn how on YOU Tube

www.armcon.com

www.youtube.com/user/armcontechtips

service@armcon.com

SERVICE LINE: 01625 856 699