

Flap Valve

Opening pressures
The original maintenance free flapvalve



D	Opening pressure (above water) mm	Opening pressure (under water) mm	Angle
100	15	5	0
125	15	5	0
150	20	10	0
200	20	10	0
250	25	15	0
300	30	20	0
400	45	20	0
500	52	28	0
600	110	42	0
700	120	45	0
800	130	47	0
900	130	50	0
1000	140	53	0
1200	155	57	0
1250	160	60	0
1500	180	62	0

D	Opening pressure (above water) mm	Opening pressure (under water) mm	Angle
100	30	15	15
125	30	15	15
150	40	20	15
200	40	20	15
250	50	20	15
300	55	30	15
400	60	30	15
500	100	39	15
600	140	57	15
700	146	61	15
800	155	64	15
900	166	68	15
1000	172	72	15
1200	180	77	15
1250	193	81	15
1500	206	86	15



Aquatic Control Engineering Ltd
01777 249080
info@aquaticcontrol.co.uk

Head Office
Hall Farm
Main Street
Rampton
Retford
Nottinghamshire
DN22 0HR