## CARE GUIDE

## POP UP BANNERS



## **Indoor Banners**

- Never fold or bend your vinyl banner
- Always use the carry bag supplied for transportation
- Do not expose to moisture, excessive heat or direct sunlight
- Ensure that the pole is firmly twisted and locked in position when assembling
- Indoor banners are only suitable for indoor use

## **Outdoor Banners**

- The blizzard outdoor banners we supply have been quality tested to ensure they are fit for purpose. These banners are stable and can cope with wind speeds up to Beaufort Scale 4.
- The banner unit weighs only 3.2kgs when empty and 19kgs when filled with water
- Fill the base with 15 litres of water. This is the adequate weight for your unit to remain sturdy
- Regularly empty water and re-fill with fresh to prevent any smell occurring
- Take care of your banner in extreme conditions to prevent danger from falling parts
- Ensure that the pole is firmly twisted and locked in position when assembling
- Never fold or bend your vinyl banner
- Always use the carry bag supplied for transportation



For a range of useful resources, advice and guidance on printing, garments and signage check out the Print Solutions online resources hub: **www.myprintsolutions.co.uk** 

