



Manual UCS pullbar clicker 2

Article number: 820.072

Removing a broken clicker




- To remove a broken clicker use an plyer.







- Grab the part at one side
- Lift the part so that there will be space for the plyer.


- Slide the plyer under the broken part.




- Grab the part
- Rotate gently backwards

- Move and pull the part backwards.
- The part will completely come of or breaks at the end.
- Remove the broken end gently by hand or arend. By sliding the part out.

<p>1.</p> 	<p>2.</p> 
<ul style="list-style-type: none">- First you push the product a little into the rubber.- This way the point of the product will come under the glider.	<ul style="list-style-type: none">- Then you slide the clicker underneath the glider.- Until you don't see the point of the glider.-
<p>3.</p> 	<p>4.</p> 
<ul style="list-style-type: none">- Then turn over the clicker backwards over the glider.	<ul style="list-style-type: none">- You push more the clicker backwards



- Push backwards until you hear a click.



- This is the final assembled position
- The clicker must be positioned in the middle.
- Check if the clicker doesn't come off easily.

