


POST PURCHASE REMOVAL

PLEASE REMOVE PART "Y" FROM YOUR KIDCO MODEL GATE NUMBER G2300, G2301, G2302, G2303, G2400, G2401, G2402

Step 1: INSERT PEN INTO HOLE OF UPPER LATCH AND PULL STOP CLIP (PART "Y")

Step 2: DISPOSE OF PART "Y" – KEEP AWAY FROM CHILDREN – SMALL PART

STEP 1



1. Insert pen into hole
2. Pull stop clip to remove

STEP 2



**CAUTION: SMALL PART
KEEP AWAY FROM CHILDREN
DISPOSE OF PROPERLY**

If you need further assistance, please contact KidCo at (855) 847 - 8600



1013 Technology Way, Libertyville, IL 60048, USA