



# R SPACE LAMP

## User Manual



## Product Packing List

This product includes one R Space Lamp, one guidance user manual, one USB charging lead and one remote control from the packaging box.



R Space Lamp



Remote Control



User Manual



USB charging Lead

## Product Set Up

1. Take out the product, charging lead and remote control from the packing box and place on an even table surface.
2. Connect the USB charging lead to any USB port such as a USB phone charger or usb port on a powered on computer or laptop to fully charge up this product first before first time use as below reference image.




Product Charging Reference Image  
(as left)

3. The charging indication light should be in red when in charging and will turn into green when fully charged.
4. You may also keep the charging lead permanently plugged in when the product is in use or when it's opened. In this case, you can use the remote control to turn off the light (see below for more details about this operation)

## Remote Control

The remote control can be used to turn on and turn off the product. It can also be used to adjust the light mode and brightness. See below for an illustrated introduction of the remote control's functions.



## The R Space Lamp Operating Instructions (Unfold the R Space Lamp with care)

1. Open the R space lamp carefully by holding the top, front, and back covers, and not the legs of the lamp, then unfold it to a full 360 degrees. Once the lamp is fully unfolded, the front and back covers should snap together magnetically and the legs should be automatically positioned by themselves.
2. Once unfolded, the LED light should instantly light up either in cool white led light or warm white led light.
3. To change the light mode, use the remote control and press the MODE + or MODE - button to change it. There are 3 light modes in total:
  - i, cool white light mode
  - ii, warm white light mode
  - iii, automatically changing between cool white and warm white light modes.
4. You can also adjust the light mode by folding and unfolding the R Space lamp. Every time it opens, it changes itself to a different light mode between that 3 modes above.

5. The charging cable can be permanently plugged in the charging port of the lamp. In this case, please use the remote control to do the light control.
6. You may also use one remote control to control multiple R Space Lamps.
7. If the lamp does not respond to the remote control, make sure you're operating from within a 3-5m distance.
8. Battery life: the lamp battery should last up to 7-8 hours after a good 3-4 hours charge. You may also need to replace the remote control battery every 2-3 years, depending on your usage.

## **Product Care & Warranty**

1. This product is made of wood, so please don't place it in a damp or humid environment such as a bathroom etc.
2. Please unfold and fold up the product carefully as auto-positioning string on the legs and the spine are fragile.
3. A heavy drop or a drop from a high table or shelf may damage the product. Please place it at a safe place.
4. Please do not use any charging adapter to charge the product if its output is more than 6V.
5. Do not disassemble this product without manufacturer's authorization as this could seriously damage the product and invalidate the manufacturer warranty.
6. Any damage caused by operating/user errors may not be covered by the manufacturer's warranty.
7. This product comes with a standard one year manufacturer's warranty from the date of purchase.

[www.ging-ko.co.uk](http://www.ging-ko.co.uk)

Copyright © Gingko Electronics Ltd

All rights are registered and protected

Alle Rechte sind eingetragen und geschützt

Todos los derechos están registrados y protegidos

[support@ging-ko.co.uk](mailto:support@ging-ko.co.uk)

Printed in China

