

Adjustable backrest Instructions

Please read fully before using the backrest

Please ensure the backrest fits the bath correctly.

- This can be checked by pushing the backrest onto the bottom of the bath then pulling up to ensure suction is occurring.
- Check that the handle reaches the outer edges of the bath on both sides.

To set the angle on the backrest-

- Slide the handle bar through the selected holes on the side of the backrest.
- Place backrest handle bar onto the rim of the bath.
- Make sure the Handle bar moves up from the holes into the slots. This will prevent the handle bar from moving.
- Lower the bottom of the backrest onto the base of the bath and check suckers are attached to the bath.

To remove the backrest-

- Lift the bottom of the backrest by pulling up the suckers then the backrest can be moved.
- To Move the handle bar push the bar down from the slots into the holes and slide the bar out.

If the backrest does not fit correctly or is damaged in any way contact your supplier and do not use it.

www.aguapadding.co.uk