

**LISTER (OWN IMPORTS)**

**CODE                      REF.                      DESCRIPTION**  
**KODE                      VERW.                    BESKRYWING**

**LT1 & 2**

<b>MK201-12380</b>	<b>LT/LR/SR</b>	<b>THRUST WASHER (SET OF 4)</b>
<b>MK601-30060</b>	<b>LT/LV</b>	<b>MAIN BEARING GEAR END STD</b>
<b>MK601-30060 /020</b>	<b>LT/LV</b>	<b>MAIN BEARING GEAR END 0.50mm</b>
<b>MK601-30060/030</b>	<b>LT1/LV1</b>	<b>MAIN BEARING GEAR END 0.75mm</b>
<b>MK601-30060/040</b>	<b>LT/LV</b>	<b>MAIN BEARING GEAR END 1.00mm</b>
<b>MK601-30061</b>	<b>LT1/LV1</b>	<b>MAIN BEARING FLYWHEEL END STD</b>
<b>MK601-30061/020</b>	<b>LT1/LV1</b>	<b>MAIN BEARING FLYWHEEL END 0.50mm</b>
<b>MK601-30061/030</b>	<b>LT/LV</b>	<b>MAIN BEARING FLYWHEEL END 0.75mm</b>
<b>MK601-30061/040</b>	<b>LT/LV</b>	<b>MAIN BEARING FLYWHEEL END 1.00mm</b>
<b>MK601-30321</b>	<b>LT</b>	<b>VALVE GUIDE EXHAUST</b>
<b>MK601-30361</b>	<b>LT</b>	<b>VALVE INLET</b>
<b>MK601-30372</b>	<b>LT/LV</b>	<b>VALVE EXHAUST</b>
<b>MK601-37020</b>	<b>LT</b>	<b>INJECTOR NOZZLE (TIP) (OLD TIPE LONG)</b>
<b>MK601-39550</b>	<b>LT/TS/TR</b>	<b>OIL SEAL</b>
<b>MK601-40602</b>	<b>LT</b>	<b>CYLINDER HEAD BARE</b>
<b>MK601-41140</b>	<b>LT</b>	<b>PISTON PIN BUSH</b>
<b>MK601-41800</b>	<b>LT</b>	<b>VALVE GUIDE INLET</b>
<b>MK601-50400</b>	<b>LT</b>	<b>RING SET STD</b>
<b>MK601-50400/020</b>	<b>LT</b>	<b>RING SET 0.50mm</b>
<b>MK601-50400/030</b>	<b>LT</b>	<b>RING SET 0.75mm</b>
<b>MK601-50400/040</b>	<b>LT</b>	<b>RING SET 1.00mm</b>
<b>MK601-50420</b>	<b>LT/LV</b>	<b>CONROD BEARING STD</b>
<b>MK601-50420-010</b>	<b>TL/LV</b>	<b>CONROD BEARING 0.25mm</b>
<b>MK601-50420/20</b>	<b>LT/LV</b>	<b>CONROD BEARING 0.50mm</b>
<b>MK601-50420/030</b>	<b>LT/LV</b>	<b>CONROD BEARING 0.75mm</b>
<b>MK601-50420/040</b>	<b>LT/LV</b>	<b>CONROD BEARING 1.00mm</b>
<b>MK601-51145</b>	<b>LT</b>	<b>PISTON &amp; RINGS STD</b>
<b>MK601-51145/020</b>	<b>LT</b>	<b>PISTON &amp; RINGS 0.50mm</b>
<b>MK601-51145/030</b>	<b>LT</b>	<b>PISTON &amp; RINGS 0.75mm</b>
<b>MK601-51145/040</b>	<b>LT</b>	<b>PISTON &amp; RINGS 1.00mm</b>
<b>MK601-56192</b>	<b>LT</b>	<b>INJECTOR NOZZLE(TIP)NEW TYPE SHORT</b>
<b>MK602-36270</b>	<b>LT/LV</b>	<b>CENTRE MAIN BEARING STD</b>
<b>MK602-36270/020</b>	<b>LT/LV</b>	<b>CENTRE MAIN BEARING 0.50mm</b>
<b>MK602-36270/30</b>	<b>LT/LV</b>	<b>CENTRE MAIN BEARING 0.75MM</b>
<b>MK602-36270/40</b>	<b>LT/LV</b>	<b>CENTRE MAIN BEARING 1.00mm</b>
<b>MK657-28576</b>	<b>LT</b>	<b>GASKET SET</b>
<b>MK660-14180</b>	<b>LT</b>	<b>PLUNGER &amp; BARREL</b>
<b>MK601-50172</b>	<b>LT</b>	<b>LUBRICATION OIL PUMP</b>
<b><u>LISTER SL1 &amp; 2</u></b>		
<b>MK657-10033</b>	<b>SL1</b>	<b>GASKET SET</b>
<b>MK657-10074</b>	<b>SL2</b>	<b>GASKET SET</b>

CODE	REF.	DESCRIPTION
KODE	VERW.	BESKRYWING

**LISTER LR &LD**

<b>MK570-11308</b>	LR/LD	PISTON & RINGS STD
<b>MK570-11308/020</b>	LR/LD	PISTON & RINGS 0.50mm
<b>MK570-11308/030</b>	LR/LD	PISTON & RINGS 0.75mm
<b>MK570-11308/040</b>	LR/LD	PISTON & RINGS 1.00mm
<b>MK570-12120</b>	LR	RING SET STD (3.14X2.34X2.34X4X4)
<b>MK570-12120/20</b>	LR	RING SET 0.50mm (3.14X2.34X2.34X4X4)
<b>MK570-12120/30</b>	LR	RING SET 0.75mm (3.14X2.34X2.34X4X4)
<b>MK570-12120/040</b>	LR	RING SET 1.00mm (3.14X2.34X2.34X4X4)
<b>MK570-12110</b>	LD	RING SET STD (3.88 X2.34X2.34X4X4)
<b>MK570-12110/020</b>	LD	RING SET 0.50mm (3.88 X2.34X2.34X4X4)
<b>MK570-12110/030</b>	LD	RING SET 0.75mm (3.88 X2.34X2.34X4X4)
<b>MK570-12110/040</b>	LD	RING SET 1.00mm (3.88 X2.34X2.34X4X4)
<b>MK201-10150</b>	LR/LD	PISTON PIN BUSH

<b>MK570-12180</b>	LR/LD/SL	CONROD BEARING STD
<b>MK570-12180/10</b>	LR	CONROD BEARING 0.25 mm U/S
<b>MK570-12180/020</b>	LR/LD/SL	CONROD BEARING 0.50mm
<b>MK570-12180/030</b>	LR/LD/SL	CONROD BEARING 0.75mm
<b>MK570-12180/040</b>	LR/LD/SL	CONROD BEARING 1.00mm
<b>MK201-12063</b>	LR	INJECTOR NOZZLE (TIP)
<b>MK660-10020</b>	LR/LD/SL	PLUNGER & BARREL
<b>MK201-19360</b>	LR	INLET & EXHAUST VALVE (SET)
<b>MK201-70380</b>	LR	INLET VALVE GUIDE
<b>MK201-70390</b>	LR	EXHAUST VALVE GUIDE
<b>MK657-17045</b>	LR1	GASKET SET /OVERHAUL JOINT
<b><u>LISTER SR</u></b>		
<b>MK201-13117</b>	SR/ST	FUEL FILTER
<b>MK201-11613</b>	SR/ST	FUEL FILTER ASSY
<b>MK201-50432</b>	SR	FUEL PUMP ASSY

<b>MK201-50540</b>	SR	CONROD BUSH
<b>MK570-10940</b>	SR	PISTON & RINGS STD
<b>MK570-10940/020</b>	SR	PISTON & RINGS 0.50 mm
<b>MK570-10940/030</b>	SR	PISTON & RINGS 0.75 mm
<b>MK570-10940/040</b>	SR	PISTON & RINGS 1.00 mm
<b>MK570-12140</b>	SR	RING SET STD
<b>MK570-12140/010</b>	SR	RING SET 0.25mm
<b>MK570-12140/020</b>	SR	RING SET 0.50mm
<b>MK570-12140/030</b>	SR	RING SET 0.75mm
<b>MK570-12140/040</b>	SR	RING SET 1.00mm
<b>MK570-12170</b>	SR	CONROD BEARING STD
<b>MK570-12170/010</b>	SR	CONROD BEARING 0.25mm U/S
<b>MK570-12170/020</b>	SR	CONROD BEARING 0.50mm
<b>MK570-12170/030</b>	SR	CONROD BEARING 0.75mm
<b>MK570-12170/040</b>	SR	CONROD BEARING 1.00mm

CODE KODE	REF. VERW.	DESCRIPTION BESKRYWING
--------------	---------------	---------------------------

MK204-52330	SR	THRUST WASHER (SET OF4)
MK201-50060	SR/LR	MAIN BEARING STD
MK201-50060/010	SR	MAIN BEARING 0.25MM
MK201-50060/020	SR/LR	MAIN BEARING 0.50mm
MK201-50060/030	SR/LR	MAIN BEARING 0.75mm
MK201-50060/040	SR/LR	MAIN BEARING 1.00mm
MK570-11171	SR/LR	CENTRE MAIN BEARING STD
MK570-11171/020	SR/LR	CENTRE MAIN BEARING 0.50mm
MK570-11171/030	SR/LR	CENTRE MAIN BEARIND 0.75mm
MK570-11171/040	SR/LR	CENTRE MAIN BEARING 1.00mm
MK201-10400	SR	INLET VALVE GUIDE (OLD TYPE)
MK201-10321	SR	EXHAUST VALVE GUIDE (OLD TYPE)
MK201-50871	SR	INLET VALVE
MK201-50891	SR	EXHAUST VALVE
MK657-10748	SR1	GASKET SET
MK657-10768	SR2	GASKET SET
MK657-10789	SR3	OVERHAUL JOINT GASKET SET
MK660-13130	SR	PLUNGER & BARREL
MK201-50461	SR	INJECTOR NOZZLE (TIP) (HL140S25C544)

#### LISTER ST

MK570-12840	ST/TS	PISTON & RINGS STD
MK570-12840-010	ST/TS	PISTON ASSY 0.25
MK570-12840/020	ST/TS	PISTON & RINGS 0.50mm
MK570-12840/030	ST/TS	PISTON & RINGS 0.75mm
MK570-12840/040	ST/TS	PISTON & RINGS 1.00mm
MK570-12910	ST/TS	RING SET STD
MK570-12910-010	ST/TS	RING SET 0.25mm
MK570-12910/020	ST/TS	RING SET 0.50mm
MK570-12910/030	ST/TS	RING SET 0.75mm
MK570-12910/040	ST/TS	RING SET 1.00mm
MK570-12980	ST	CONROD BEARING STD
MK570-12980/010	ST	CONROD BEARING 0.25mm
MK570-12980/020	ST	CONROD BEARING 0.50mm
MK570-12980/030	ST	CONROD BEARING 0.75mm
MK570-12980/040	ST	CONROD BEARING 1.00mm
MK570-12960	ST	THRUST WASHER (SET OF 4)
MK570-12970	ST	MAIN BEARING STD
MK570-12970-010	ST	MAIN BEARING 0.25
MK570-12970/020	ST	MAIN BEARING 0.50mm
MK570-12970/030	ST	MAIN BEARING 0.75mm
MK570-12970/040	ST	MAIN BEARING 1.00MM
MK570-12990	ST/TS2&3	CENTRE MAIN BEARING STD
MK570-12990/010	ST	CENTRE MAIN BEARING 0.25MM
MK570-12990/020	ST/TS2&3	CENTRE MAIN BEARING 0.50mm
MK570-12990/030	ST/TS2&3	CENTRE MAIN BEARING 0.75mm
MK570-12990/040	ST/TS2&3	CENTRE MAIN BEARING 1.00mm
MK570-13001	ST	CONNECTING ROD

**KODE VERW. BESKRYWING**

<b>MK570-13043</b>	ST	CYLINDER HEAD BARE
<b>MK201-12510</b>	ST	STARTING HANDLE
<b>MK201-10171</b>	<b>ST</b>	CAMSHAFT BUSH END COVER
<b>MK201-10181</b>	<b>ST/SR</b>	CAMSHAFT BUSH GEAR END
<b>MK201-13190</b>	ST	OIL SEAL
<b>MKST1-OIL PUMP</b>	ST	LUBRICATION OIL PUMP
<b>MK201-50432</b>	ST	FUEL PUMP ASSY
<b>MK201-55640</b>	ST/SR	VALVE GUIDE INLET
<b>MK201-55650</b>	ST/SR	VALVE GUIDE EXHAUST
<b>MK201-80061</b>	ST	CYLINDER BARREL
<b>MK201-80230</b>	ST	VALVE SPRING CARRIER
<b>MK201-80250</b>	ST	INLET VALVE
<b>MK201-80241</b>	ST	EXHAUST VALVE
<b>MK201-80310</b>	ST/TS/TR	CONROD SMALL END BUSH
<b>MK657-23516</b>	ST1	GASKET SET
<b>MK657-23535</b>	ST2	GASKET SET
<b>MK657-23557</b>	ST3	GASKET SET
<b>MK660-13760</b>	ST	PLUNGER & BARREL (PUMP ELEMENT)
<b>MK660-11050</b>	ST/SR/LR	DELIVERY VALVE
<b>MK201-11662</b>	ST	T-PIECE
<b>MK201-80270</b>	ST	CAMSHAFT BUSH FLY WHEEL END
<b>MK201-81393</b>	ST	INJECTOR NOZZLE (TIP)
<b>MK201-55370</b>	ST	LUBRICATING OIL FILTER
<b>MK202-12030</b>	ST	CAMSHAFT BUSH CENTRE
<b>MK351-29760</b>	ST3	FUEL FILTER
<b>MK366-06211</b>	ST	AIR FILTER ASSY
<b>MK366-06227</b>	ST	AIR FILTER ELEMENT
<b>MK366-08126</b>	ST/TS/TR	OIL FILLER CAP

**LISTER TS**

<b>MK570-31370</b>	TS/TR	CONROD BEARING STD
<b>MK570-31370/010</b>	TS/TR	CONROD BEARING 0.25mm
<b>MK570-31370/020</b>	TS/TR	CONROD BEARING 0.50mm
<b>MK570-31370/030</b>	TS/TR	CONROD BEARING 0.75mm
<b>MK570-31370/040</b>	TS/TR	CONROD BEARING 1.00mm
<b>MK570-30261</b>	TS/TR	CONNECTING ROD
<b>MK570-31360</b>	TS/TR	THRUST WASHERS (SET OF4)
<b>MK570-30010</b>	TS/TR	MAIN BEARING GEAR END
<b>MK570-30010/010</b>	TS/TR	MAIN BEARING GEAR END 0.25mm
<b>MK570-30010/020</b>	TS/TR	MAIN BEARING GEAR END 0.50mm
<b>MK570-30010/030</b>	TS/TR	MAIN BEARING GEAR END 0.75mm
<b>MK570-30010/040</b>	TS/TR	MAIN BEARING GEAR END 1.00mm
<b>MK570-30011</b>	TS/TR	MAIN BEARING FLYWHEEL END STD
<b>MK570-30011/010</b>	TS/TR	MAIN BEARING FLYWHEEL END 0.25mm
<b>MK570-30011/020</b>	TS/TR	MAIN BEARING FLYWHEEL END 0.50mm
<b>MK570-30011/030</b>	TS/TR	MAIN BEARING FLYWHEEL END 0.75mm

**KODE                      VERW.                      BESKRYWING**

<b>MK570-30011/040</b>	TS/TR	MAIN BEARING FLYWHEEL END 1.00mm
<b>MK201-10171</b>	ST	CAMSHAFT BUSH END COVER
<b>MK201-10181</b>	ST/SR	CAMSHAFT BUSH -GEAR END
<b>MK201-30181</b>	TS/TR	INLET VALVE GUIDE
<b>MK201-30172</b>	TS/TR	EXHAUST VALVE GUIDE
<b>MK201-30040</b>	TS	INLET VALVE
<b>MK201-30051</b>	TS	EXHAUST VALVE
<b>MK201-41940</b>	TS/TR	OIL SEAL
<b>MK657-32681</b>	TS1	GASKET SET
<b>MK657-29511</b>	TS2	GASKET SET
<b>MK657-29530</b>	TS3	GASKET SET
<b>MK660-14260</b>	TS/TR	PLUNGER & BARREL (PUMP ELEMENT)
<b>MK660-14270</b>	TS/TR/LT	DELIVERY VALVE
<b>MK201-81395</b>	TS	INJECTOR NOZZLE(201-90463)OLD MODEL
<b>MK201-47062</b>	TS	INJECTOR NOZZLE(201-47042)NEW MODEL
<b>MK366-08126</b>	TS/ST/TR	OIL FILLER CAP
<b>MK570-31000</b>	TS/TR	STARTING HANDLE
<b>MK366-07188</b>	TS	AIR FILTER ELEMENT
<b>MK751-18100</b>	TS/TR	FUEL FILTER (FITS LPW)

**LISTER TR**

<b>MK570-33360</b>	TR	PISTON & RINGS STD
<b>MK570-33360/020</b>	TR	PISTON & RINGS 0.50mm
<b>MK570-33360/030</b>	TR	PISTON & RINGS 0.75mm
<b>MK570-33360/040</b>	TR	PISTON & RINGS 1.00mm
<b>MK570-33370</b>	TR	RING SET STD
<b>MK570-33370/020</b>	TR	RING SET 0.50mm
<b>MK570-33370/030</b>	TR	RING SET 0.75mm
<b>MK570-33370/040</b>	TR	RING SET 1.00mm
<b>MK201-33070</b>	TR	INLET VALVE
<b>MK201-33080</b>	TR	EXHAUST VALVE
<b>MK201-47092</b>	TR	INJECTOR NOZZLE (201-47072 NEW MODEL)
<b>MK202-36720</b>	TR	INJECTOR NOZZLE (202-36730 OLD MODEL)
<b>MK657-33091</b>	TR1	GASKET SET
<b>MK657-33371</b>	TR2	GASKET SET
<b>MK657-33390</b>	TR3	GASKET SET

**LISTER HR**

<b>MK572-50622</b>	HR	RING SET STD
<b>MK657-19686</b>	HR2	GASKET SET
<b>MK657-19706</b>	HR3	GASKET SET

**LISTER LR**

<b>MK201-12063</b>	LR	NOZZLE (INJECTOR TIP)
<b>MK570-11308</b>	LR	PISTON ASSY STD

<u>CODE</u>	<u>REF.</u>	<u>DESCRIPTION</u>
<u>KODE</u>	<u>VERW.</u>	<u>BESKRYWING</u>

<b>MK570-11308-020</b>	LR	PISTON ASSY 0.50
<b>MK570-11308/030</b>	LR	PISTON ASSY 0.75mm
<b>MK570-11308-040</b>	LR	PISTON ASSY 1.00mm

#### LISTER LPW

<b>MK750-13120</b>	LPW	RING SET STD
<b>MK750-11260</b>	LPW	CONROD BEARING STD
<b>MK750-13120/020</b>	LPW	RING SET 0.50MM
<b>MK750-11230</b>	LPW	THRUST WASHERS(SET OF4)
<b>MK750-11210</b>	LPW	MAIN BEARING STD (FLYWHEEL END)
<b>MK750-11240</b>	LPW	MAIN BEARING STD (GEAR END)
<b>MK750-11250</b>	LPW	CENTRE MAIN BEARING STD
<b>MK750-41610</b>	LPW	PISTON ASSY STD
<b>MK750-41610-020</b>	LPW	PISTON ASSY 0.50MM
<b>MK750-41610-0E</b>	LPW	PISTON ASSY STD (ORIGINAL)
<b>MK657-34281</b>	LPW4	GASKET SET EX HEAD GASKET
<b>MK751-15871</b>	LPW	INJECTOR NOZZLE (TIP)

#### PETTER PH

<b>MK193374</b>	PH	STARTING HANDLE
<b>MK294661</b>	PH	CONNECTING ROD
<b>MK334273</b>	PH	BOTTOM GASKET SET
<b>MKM3405</b>	PH	MAIN BEARING SET
<b>MK257762</b>	PH	THRUST WASHER (SET OF 2)
<b>MK359503</b>	PH	TOP GASKET SET
<b>MK364789/HJC113</b>	PH	RING SET STD
<b>MK364790/HJC113</b>	PH	RING SET 0.50
<b>MK364791/HJC113</b>	PH	RING SET 1.00mm
<b>MK392954</b>	PH	PETTER INLET & EXHAUST VALVE GUIDES
<b>MK392989</b>	PH	PETTER CONROD BEARING (STD)

# MOST LISTER, HATZ & PETTER SPARES AVAILABLE ON REQUEST

THIS LIST REPLACES ALL PREVIOUS ISSUES & IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE

HIERDIE PRYSLYS VERVANG ALLE VORIGE UITGAWES & IS ONDERHEWIG AAN VERANDERING SONDER

VOORAF KENNISGEWING