




F1. SOLENDID VALVE ASSY.




F1. SOLENDID VALVE ASSY.




F2. ENGINE HANGER / MUFFLER




F3. PLASTIC COVERS




F3. PLASTIC COVERS



F4. FRAMES




F4. FRAMES




F5. WHEELS


FR



F6. CONTROL CABLES





F7. BRAKE SYSTEM




FR


F8. STEERING MECHANISM




F9. SWING A ARMS




F10. DRIVING SHAFT, ABSORBER






F11. REAR RACK




F12. FRONT BUMPER, HEAD LAMP




F14. DASHBOARD , COVER




F15. COOLING SYSTEM




F15. COOLING SYSTEM




F16. ELECTRIC PARTS




F16. ELECTRIC PARTS



BR-500 LABELS



1



2



3



4




5



6




7



8



9



10




13




14




11




12




15



16



17



18



19



20



21