

# Wireless Pouch™ Adaptor Kit


1. The Wireless Pouch™ Adaptor Kit is designed exclusively to be used with the Neotech Wireless Pouch™ (sold separately). The kit consists of three items: one Leather adaptor, one 36" length of Velcro® receptive elastic, and one Velcro® hook tab.
2. The Wireless Pouch™ Adaptor Kit can be used to rotate the orientation of your transmitter 90° if you so desire, by using the leather adaptor.



Wireless Pouch Alone      Wireless Pouch with Adaptor

4. Using the elastic and velcro tab, the Wireless Pouch™ Adaptor can be worn beneath costumes or clothing to conceal the transmitter for theatre, film or video. The elastic is comfortable for the performer, while the neoprene wireless pouch protects transmitters against impact and moisture.

3. The Wireless Pouch™ Adaptor can be fastened to a strap or belt from 1" to 3" wide simply by fastening the tabs of the Wireless pouch around the leather adaptor as shown to the right.



Worn across the shoulder



a division of

**OP/TECH USA**®

www.neotechstraps.com  
800-251-7815