

# **PRIMERS**

# surface preparation for optimum bonding

#### What is it?

Certain materials need a modification of their surface to be bonded and/or ensure a durability of the assembly. The application of a primer is a mean to transform the substrate into a modified surface in a chemical and/or a physical way, in order to reinforce the adherence in long term.

### What are the effects?

Axson primers offer a triple action:

1 Improve the performance of the bonding, offering a better adherence and a better aging resistance.

2 Create a barrier against plasticizers and additives present in the glue, avoiding discolouration and stress cracking\* for the bonding of thermoplastics.

• Chemical attack of the plastic degrading mechanical properties of the material (tear strength + elongation) and which weakens it during thermal expansion.



#### How to use them well?

Before use of the primer, for a maximum performance, the surface to be bonded must be clean and dry. The previous application of the Adekit Cleaner is recommended in order to get a surface free from contaminants (dust, grease, etc).

- Shake the bottle of Primer before use
- Close it immediately after use
- The product must be used within the recommended period

Protect and stabilise metallic surfaces for Metal Primer.

## How to apply them?

Primers are applied either with a foam sponge, a felt pad, a paintbrush or by spraying with a gun.

- Apply primer in a continuous move with a slight and uniform pressure in order to get a thin and homogeneous layer.
- Allow primer to dry before applying the adhesive.

#### Technical datas

	GLASS PRIMER	PLASTIC PRIMER	METAL PRIMER
Code	Z35850	Z35670	06626
Substrate	Glass and Plastic	Plastic	Metal
Colour	Black	Transparent	Ochre
Density	0,90 ± 0,05	0,94 ± 0,02	1,00 ± 0,03
Drying time Touch dry	15 min at 20°C	5 min at 20°C	10 to 15 min at 23°C
Drying time before adhesive application	15 min at 20°C	20 min at 20 °C	25 to 30 min at 23°C
Application temperature	10 to 35 °C	10 to 35 °C	10 to 35 °C

#### Packagin



A: GLASS PRIMER: 12x250ml

B: PLASTIC PRIMER transparent: 12x500ml

C: METAL PRIMER: 1x1000ml



D: ADEKIT CLEANER: 6x1000ml