










Cyalume® LightStation® Recharge/Refill Instructions.

Please note: For operation and safety, Cyalume® LightStations® should only be recharged/refilled with genuine Cyalume® lightstick 10" refills. Available from all Cyalume® Official Distributors.

PART ONE - Preparation		
 <p>With the LightStation® in the open position.</p>	 <p>Load one Lightstick refill into the capture feature. (Models Vary)</p>	 <p>Load the LightStation® with Lightstick refills into the tilt bar (Models Vary)</p>
 <p>Raise the cover by 90 degree so the LightStation® can be put into the 'set' position.</p>	 <p>Slide capture feature into closed position. (Models Vary)</p>	 <p>Ensure the tilt bar is slid up and aligned with tilt bar slots (Models Vary)</p>
 <p>Ensure Lightstick refills are pushed back into position</p>	<p>THE LIGHTSTATION IS NOW READY TO BE CLOSED.</p>	
PART TWO – Closure and Security		
 <p>Quickly swing the cover up so the LightStation closes all the way.</p>		
 <p>Finally insert tamper pins and/or locks to the lightstation (dependent on model)</p>		

For more information please contact your Cyalume® Official Distributor.



When Your Safety Depends On Light... Depend On LumiSafe.

Website: <http://www.lumisafe.co.uk> Email: lumisafe@btconnect.com