



OPERABLE PARTITION

MARKER BOARD CLEANING INSTRUCTIONS

INITIAL CLEANING

- Wipe with a soft dry cloth or clean, dry eraser.
- Only use liquid whiteboard cleaners as directed on the cleaner's instruction label.
- Allow the surface to dry 2 hours before use.

FOR DAILY USE:

- Always allow the dry erase marker to dry completely before erasing.
- Always use a dry erase eraser or a soft cloth to remove the marker.
- **All marks must be removed before using liquid dry erase whiteboard cleaner. Never use liquid whiteboard cleaner to remove wet marker ink.**
- If whiteboard cleaner not available, use a mild soap and water. Rinse with clean water and wipe with a soft dry cloth.

CAUTIONS:

- Do not use strong solvents or cleaners on the marker board.
- Do not use cleaners with abrasives.
- Do not remove dry erase markers with wet towelettes such as "Erasettes".
- Do not remove dry erase marks directly with liquid dry erase whiteboard cleaner or with 70% Isopropyl Alcohol.
- We recommend Expo®, Marks-a-Lot®, and Quartet® dry erase markers. Some colors are more prone to leave shadows.

For complete cleaning instructions, visit
www.hufcor.com/operable-partitions-maintenance-cleaning