

PolyAqual™ 2W Pure Water Gel

Reference: TR 04-44B

INCI name	%	Function
PHASE A		
Water (<i>Aqua</i>)	up to 100.00	
Polyglyceryl-2 Stearate (<i>and</i>) Glyceryl Stearate (<i>and</i>) Stearyl Alcohol - PolyAqual™ 2W	5.00	Auto-Emulsifier
PHASE B		
Preservative	a.n.	Preservative
VISCOSITY after 24h Brk, RVDV-I Prime, Sp 92, 10 rpm 5000 – 11000 cps		pH (100%) 5.0 – 7.0

Procedure:

- Prepare the water phase and warm it up to 75 - 80°C;
- Disperse the emulsifier in the water phase using a suitable dispersion unit;
- Homogenize for a few minutes;
- Cool down under gentle stirring;
- Add the preservative below 40°C