



## **Installation Guide — Green Frog Anti-Marking Jackets**

### **Heidelberg Speedmaster 102 (U1/U3) Transfer Positions R/P**

#### **Prior to installation:**

Required Tools: 13mm Hex Head Wrench

#### **Removal of any Existing Transfer Jackets:**

Please review the instructions provided by the press manufacturer concerning removal of any transfer jackets the press may be equipped with, as these are supplemental instructions and it is always best to refer to the manufacturer's instructions prior to removal of existing transfer jackets. Be sure to observe all warning, safety and lock out procedures.

#### **Preparing the Transfer Cylinder Surface:**

Once any transfer jackets have been removed, clean the cylinder surface using a mild solvent and a lint free cloth, remove any debris or other foreign substances from the cylinder surface. The Green Frog Anti-Marking Jacket is installed in a similar manner as the original transfer jackets provided by the press manufacturer. These are supplemental instructions and it is best that you also refer to the manufacturer's original instructions. The textured glass beaded side of the jacket faces up, which contacts and supports the printed substrate. The Green Frog Jacket has a backing attached to the underside of the jacket which acts as a packing material. If you are printing stocks 200gsm or lighter it may be necessary to add packing under the jacket during the installation process. The recommended clearance between the impression cylinder and the surface of the Green Frog Jacket is between .024" (0.6mm) and .039" (1.0mm). In most cases it is not necessary to add packing to the Green Frog Jacket, if you are unsure, please contact us for additional information.

#### **Installation Process:**

Once any existing transfer jackets have been removed and the cylinder surface is clean and dry, rotate the transfer cylinder so that the tail edge of the cylinder is facing upwards and accessible. Insert the tail edge of the Green Frog Jacket with the protruding retaining pins into the corresponding holes in the tail edge of the cylinder clamping mechanism. When inserting the retaining pins, be sure that they lock into place and that the "pin lock springs" have locked the retaining pins into place. Holding the opposite edge (gripper edge) of the jacket taut, slowly rotate the cylinder in the reverse direction until the gripper assembly is facing upwards and the 13mm hex head bolts are accessible (the hex head bolts are located on both side edges of the cylinder). Loosen both hex head bolts until they are loose enough to swing away from the locking position. Apply pressure outwards to both locking flanges to "unlock" the cylinder "lip" portion at the gripper edge of the cylinder. The lead edge of the cylinder can now be "flipped" open. Locate the protruding retaining pins on the underside of the open "lip" of the cylinder.

**CyanX Ltd**, Unit 1, South View Business Park, Ghyll Royd, Guiseley, Leeds, LS20 9LT

T: 0 33 33 21 85 21 F: 01943 871275 e: sales@cyanX.co.uk

Company Registration No: 5524876 VAT Registration No: 880 7371 04



# GREEN FROG

Insert the gripper edge of the Green Frog Jacket over the edge of the open "lip" of the cylinder and align the die cut areas with the round tensioning rod through them over the retaining pins on the underside of the "lip" portion of the cylinder. Be sure that the retaining rod is inserted over all the retaining pins, slowly close the open "lip" portion of the cylinder, applying pressure to the jacket, Upon closing the "lip" portion of the cylinder be sure that the locking flanges engage properly and lock the "lip" portion of the cylinder into place properly. Swing the hex head bolts back into place and tighten securely.

Rotate the transfer cylinder and inspect the surface of the Green Frog Jacket ensuring that there are no wrinkles or distortions in the surface and the jacket fits tightly over the entire transfer cylinder surface to complete the installation process. Be sure that all fixtures are securely locked into place prior to running the press.

### **Maintenance and Care of the Green Frog Anti-Marking Jacket**

The Green Frog Anti-Marking Jacket will require periodic cleaning in order to keep the surface free from ink accumulation. In most cases the surface should be washed on a daily basis in order to receive the longest service life. It is also best that the washing of the surface be performed before the ink is dried and becomes hard.

We suggest that a clean lint free cloth be used to wash the surface of the Green Frog Jacket, do not use scrubbing pads with coarse surfaces as this may scratch the surface and allow rapid ink accumulation. To remove ink or other debris from the jacket surface we suggest a mild (non Toluene based) solvent that does not contain Glycol, as these types of solvents can destroy the surface integrity and cause premature replacement.

If ink is allowed to dry on the surface, it may be necessary to wash the surface several times in order to remove any ink accumulation, It is normal to see stains appear on the surface as the coatings used to protect the Silicon Glass Beads have pores that will retain small amounts of ink pigmentation and may cause a staining effect. It is only important that dried ink does not accumulate on the jacket surface over long periods of time, as the dried ink accumulation may scratch the surface of the freshly printed substrate.

We hope that our products meet and exceed your performance requirements and expectations, if you should have any questions, please contact our customer service department on + 44 (0) 33 33 21 85 21.

**CyanX Ltd**, Unit 1, South View Business Park, Ghyll Royd, Guiseley, Leeds, LS20 9LT

**T:** 0 33 33 21 85 21 **F:** 01943 871275 **e:** sales@cyanX.co.uk

Company Registration No: 5524876 VAT Registration No: 880 7371 04