Minimate Pro4



Advanced Vibration, Overpressure and Sound Monitor

4 - Channel data acquisition for the following range of Applications:

- Blast-monitoring for compliance
- Remote monitoring -Auto Call Home™
- Near-field blast analyis
- · Sound monitoring
- Pile driving
- Construction activity
- Demolition activity
- Structural monitoring
- Underwater monitoring
- Heavy transportation

The Instantel® Minimate Pro4 vibration, overpressure and sound monitors are built on the success of the Minimate® Series III monitoring systems.

The **Minimate Pro4** offers 64MBs of memory, improved ruggedness, including a metal case and connectors, and water resistance

For reliable compliance monitoring, connect an ISEE or DIN Triaxial Geophone and an ISEE Linear Microphone or optional Sound Microphone.

Versatile

Each compliance sensors calibration date, serial number, and sample rate specification are determined by the Sensor Check feature of the unit and stored in the setup file. The sensor type, calibration date and serial number are also recorded on the Event Report.

For those challenging monitoring applications, such as tunneling, the **Minimate Pro4** monitoring unit includes EMI shielding and built-in noise and anti-aliasing filters; both the sensor and auxiliary channels are isolated.

With the optional **Instantel Blastware® Advanced Module**, perform VDV monitoring, Signature Hole Analysis and real time display of Histogram data.

Intelligent

View Peak Vibration and Zero Crossing Frequencies immediately after each Event occurs. Toggle between Peak Vibration and Peak Overpressure with a simple push of a button. Data highlights, including Operator, Trigger, Duration, and Maximum Vibration and Overpressure, are also available for review, right on the monitors display.

Remote Monitoring

For remote installations, the **Instantel Auto Call Home** feature will automatically transfer event files from field to office as they are recorded using a variety of wireless modems. From there, the **Blastware Mail** feature of the **Instantel Blastware** software automatically distributes files or summary information to multiple e-mail addresses.



Vision™

Auto Call Home integrates with **Vision**, Instantel's Cloudbased event data hosting application (optional). With **Vision**, you can store monitoring data securely in the Cloud and deliver the information your stakeholders need—anytime, anywhere, instantly. Vision also lets you:

- View, sort, filter and print event data to identify trends before they become issues.
- Map your site—using technology from Google, you can place your monitoring units on a street or satellite map.
- Upload photos for a record of the latest progress.

Easy to use

Even with all of these features, the **Minimate Pro4** system is still easy for anyone to use. A high-contrast LCD and ten-key tactile keypad drives simple menu operations, while graphic icons indicate battery and memory levels at a glance.

Key Features

- Dedicated function keys and intuitive menu-driven operation enable quick and easy setup.
- Sample rates from 512 to 65,536 S/s per channel, independent of record times.
- Continuous monitoring means zero dead time between events, even while the unit is processing.
- Instantel Histogram ComboTM mode allows capturing thousands of full waveform records while simultaneously recording in histogram mode.
- The Auto Call Home feature automates remote monitoring applications.
- Non-volatile memory with standard 8,000-plus event storage capacity.
- · Records full waveform events over two hours long.
- Match any channel with a variety of sensors; geophones, accelerometers, hydrophones and a dedicated microphone channel.
- Optional Sound Microphone available for sound monitoring.
 Combine an ISEE or DIN Triaxial Geophone with the Sound Microphone to monitor two types of event data.

General Specifications

Minimate Pro4 Channels

Geophone

Range

Response Standard

Resolution

Frequency Range (ISEE / DIN)

Accuracy (ISEE / DIN) Transducer Density

Maximum Cable Length (ISEE / DIN)

Microphone (Sold separately)

Weighting Scales Response Standard

Range

Resolution Frequency Response

Accuracy

Maximum Cable Length

Optional Advanced Sensors

Channels 1-3, ISEE or DIN Triaxial Geophone, and Channel 4, ISEE Linear or Sound Level Microphone

Up to 254 mm/s (10 in/s)

ISEE Seismograph Specification or DIN 45669-1

0.00788 mm/s (0.00031 in/s)

2 to 250 Hz, within zero to -3 dB of an ideal flat response / 1 to 315 Hz or 1 to 80 Hz

+/- 5% or 0.5 mm/s (0.02 in/s), whichever is larger, between 4 and 125 Hz / DIN 45669-1 standard

2.13 g/cc (133 lbs/ft³)

75 m (250 ft) / 1,000 m (3,280 ft)

ISEE Linear Microphone

ISEE Linear Microphone ISEE Seismograph Specification (2011)

2 to 500 Pa (0.00029 to 0.0725 psi [88 to 148 dB])

0.0156 Pa (2.2662x10⁻⁶ psi)

2 to 250 Hz between -3 dB roll off points

+/- 10% or +/- 1dB, whichever is larger, between 4 and 125 Hz

75 m (250 ft)

Sound Level Microphone

A-Weight or C-Weight Fast (125 ms) or Slow (1 s) 30 to 140 dB A or C

0.05 dB (Display limit 0.1 dB)

10 Hz to 20 kHz IEC 61672 Class 1

75 m (250 ft)

Contact Instantel for more information

High Pressure Microphone, High Frequency Geophone, Uniaxial and Triaxial Accelerometer, and Hydrophone

Waveform Recording

Record Modes Seismic Trigger Linear Acoustic Trigger

Sample Rate Record Stop Mode

Record Time AutoRecord Time

Cycle Time

Minimate Pro4 Storage Capacity

Full Waveform Events

Waveform, Waveform Manual 0.13 to 254 mm/s (0.005 to 10 in/s) 2.0 to 500 Pa (0.0029 to 0.0725 psi)

512, 1,024, 2,048, 4,096, 8,192, 16,384, 32,768, 65,536 S/s per channel (independent of record time)

Fixed record time, Instantel AutoRecordTM record stop mode

1-9,000 seconds (1-30 seconds, then 30-second increments up to 150 minutes) plus a 0.25 seconds pre-trigger Event is recorded until activity remains below trigger level for duration of auto window, or until available

memory is filled.

Recording uninterrupted by event processing, monitoring, or communication - no dead time below 65 KHz.

64 MBs. Optional 240 MBs.

8,000-plus 1-second events at 1,024 S/s sample rate

Histogram Recording

Record Modes

Recording Interval Histogram Storage Capacity

Histogram Combo Storage Capacity

Histogram and Instantel Histogram Combo (monitor captures triggered waveforms while recording in Histogram mode)

1 to 30 seconds at 1 second intervals, and 30 seconds to 60 minutes at 30 second intervals 800,000 intervals. Examples: 18.5 days at 2 second intervals, or 555 days at 1 minute

Example: 30 days of Histogram recording at 1 minute intervals, and over 7,500 1 second waveform events

Physical Specifications

Dimensions Unit Weight Battery

User Interface Display PC Interface

Auxillary Inputs and Outputs

Environmental

LCD Operating Temperature Electronics Operating Temperature

Water Resistance Remote Communications

Additional Features

Electrical Standards

25.4(l) x 11.75(w) x 10.80(h) cm (10.00 x 4.63 x 4.25 in); length dimension includes connectors and dust caps

2.27 kg (5 lbs)

10 domed tactile with separate keys for common functions 7-line x 32-character, high-contrast, multi-color backlit LCD

Ethernet® cable, supplied, for PC to unit connection (Auto Call Home is not supported over Ethernet), or

RS-232 with an optional USB adapter External Trigger and Remote Alarm

-20 to 45 °C (-4 to 113 °F) -40 to 45 °C (-40 to 113 °F)

IP67 – submerse to 30 cm (1 ft.) for 24 hours

Instantel approved serial communication modems Automatically transfers events when they occur through the Instantel Auto Call Home feature

Monitor start/stop timer

(Optional) Vision provides you and your stakeholders with secure, encrypted, Cloud-based access to the data they

need, providing instant sharing for time-sensitive projects.

CE Class B

Corporate Office:

309 Legget Drive, Ottawa, Ontario K2K 3A3 US Office:

808 Commerce Park Drive, Ogdensburg, New York 13669

Email: sales@instantel.com © 2017 Xmark Corporation. Instantel, the Instantel logo, Auto Call Home, AutoRecord, Blastmate, Blastware, Histogram Combo, InstaLink, and Minimate are trademarks of Stanley Black & Decker, Inc., or its affiliates.

Toll Free: (800) 267 9111

Telephone: (613) 592 4642

Facsimile: (613) 592 4296



The World's Most Trusted Monitors — Vibration · Noise · Air Overpressure